

**EPOMAKER**

**SK71 Keys  
Hot Swappable  
Mechanical  
Keyboard**



# EPOMAKER SK71 Keys Hot Swappable Mechanical Keyboard User Manual

[Home](#) » [EPOMAKER](#) » EPOMAKER SK71 Keys Hot Swappable Mechanical Keyboard User Manual 

## Contents

- [1 EPOMAKER SK71 Keys Hot Swappable Mechanical Keyboard](#)
- [2 Product Usage Instructions](#)
- [3 Overview](#)
- [4 Function Description](#)
- [5 FAQ](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)
- [7 Related Posts](#)

**EPOMAKER**

## EPOMAKER SK71 Keys Hot Swappable Mechanical Keyboard



# Product Usage Instructions

## Initial Setup:

Follow these steps to set up the Product XYZ:

1. Unbox the product and check for all the components.
2. Assemble the different parts according to the assembly instructions provided.
3. Connect the power source as specified in the manual.

## Basic Operation:

To operate Product XYZ, follow these basic steps:


1. Turn on the power using the designated power button.
2. Use the control panel to adjust settings such as temperature, speed, etc.
3. Follow specific instructions related to the function you wish to perform with the product.

## Maintenance:

To ensure the longevity of Product XYZ, it is important to perform regular maintenance tasks:

1. Clean the product after each use according to the cleaning instructions.
2. Check for any wear and tear on parts and replace them if necessary.
3. Store the product in a cool, dry place when not in use.

## Overview





**Item:** GK73 / GK73S / SK71 / SK71S/ SK73/ SK73S



- (SK71 / SK71S model only)

**NOTE:** Press Fn with the function keys









-  One of the blue LED is flashing, The keyboard is connecting the BT equipment.
-  Bluetooth ON/OFF switch, Link to USB mode.

## Function Description







### FN function description

(Double-click FN to light FN's white LED, FN function is held, click FN again to escape from holding status).

### Backlight settings (Can not modify)

Key	Function
FN + backspace ←	 Backlight ON/OFF
FN + O	 Backlight mode 1—5 (Can modify)
FN + P	 Backlight mode 6—9
FN + \	 Light effect pause/play
FN + ↓	 Backlight brightness
FN + ↑	 Backlight brightness +
FN + ←	 Backlight Effect Speed —
FN + →	 Backlight Effect Speed +

### BT & System settings (BT model only, can not modify)

Key	Function
<b>FN + Space</b>	 Bluetooth ON/OFF switch Link to USB mode or the last BT equipment.
<b>FN + Z</b>	*1 <u>Long press:</u> The red&green LED of Z keycap will flash. The * bluetooth equipment can be paired. <u>Press:</u> The keyboard will connect the *1 BT equipment or disconnect.
<b>FN + X</b>	*2 <u>Long press:</u> The red&green LED of X keycap will flash. The *2 bluetooth equipment can be paired. <u>Press:</u> The keyboard will connect the *2 BT equipment or disconnect.
<b>FN + C</b>	*3 <u>Long press:</u> The red&green LED of C keycap will flash. The *3 bluetooth equipment can be paired. <u>Press:</u> The keyboard will connect the *3 BT equipment or disconnect.
 <b>Note:</b> If the bluetooth pairing is timed out or failed, please re-pair. If the bluetooth pairing is successful on the equipment, but the keyboard can not work still, please delete the keyboard in the bluetooth list of the equipment and pair again.	
<b>FN + Tab</b>	 Long press for 3 seconds to lock/unlock the keyboard
<b>FN + Win</b>	 Clock/Unlock Win key
<b>EN + L - Ait</b>	 ON/OFF Low voltage&charging status indicator Logo LED&back side LED
<b>FN + L - Ctrl</b>	 Keyboard's sleep time setting, white LED flashing on 0: never sleep, 1:5minutes, 2:10minutes...9:45minutes to sleep.

**FN + function (Standard mode reference settings)**

**Tab 1**

Key	Function	Key	Function
FN + 1	F1	FN + _	/
FN + 2	F2	FN + +	•
FN + 3	F3	FN + [	]
FN + 4	F4	FN + Shift + [	}
FN + 5	F5	FN + ;	,
FN + 6	F6	FN + Shift + ;	"
FN + 7	F7	FN + ,	`
FN + 8	F8	FN + Shift + ,	~
FN + 9	F9	FN + •	/
FN + 10	F10	FN + Shift + •	?

Tab 2






Key	Function	Key	Function
FN + num 1	Del	FN + num 8	SL
FN + num 2	End	FN + num 9	PB
FN + num 3	PD	FN + num 0	-
FN + num 4	Ins	FN + num •	=
FN + num 5	HM	FN + Shift + num 0	--
FN + num 6	PU	FN + Shift + num •	+
FN + num 7	PS		

#### Media key (Standard mode reference settings)

Key	Function	Key	Function
FN + A	⏮ Play/Pause	FN + F	🔇 Mute
FN + S	⏮ Previous	FN + G	⏮ Volume —
FN + D	⏮ Next	FN + H	⏮ Volume+

#### Define mode



Key	Function
<b>Standard mode</b>	Standard mode, all buttons can not be user-defined. User can customize your own personality keyboard by the following 4 modes. On-board mode 1/2/3 is strongly recommended. (  <b>Note:</b> In the custom mode, except FN key, other keys can be redefined key values, some of the FN + "x" function can be also modified, except the backlight, bluetooth and system control. The FN button can not be moved, but user can define your own FN1/FN2/FN3 at any key on the keyboard in the custom mode).
<b>FN + Q</b> Driver mode	 FN + Q is the driver mode layer. "Q" lights white LED, some special function (For example: You may assign a macro of more than 32 bytes to a key in the driver mode while it's unavailable in those onboard mode layer) and backlights can be set in this mode. You must keep the driver running and the keyboard connect with the driver. Press FN + Q again, back to standard mode.
<b>FN + W</b> Onboard mode1 Layer1/ Fn1	 FN + W, onboard mode 1 layer 1. "W" lights white LED. no need to run and connect the driver. The keyboard works in the custom key functions and user can modify the key functions and macro Settings by the driver and these Settings can be downloaded and saved to the keyboard. The reference Setting: the multifunctional reuse Settings of the space bar, click for the regular space function. Space + other key combination to achieve the onboard mode layer3 call function. Press FN + W again, back to the standard mode
<b>FN + E</b> Onboard mode2 Layer2 / Fn2	 FN+ E, onboard mode layer2, "E" lights white LED. The reference Setting: keyboard of MAC OS, the "control, option, command" key will be in the original position. User can modify the Settings by the driver, download and save to the keyboard, no need to run and connect the driver when use the Mac's function settings. Press FN + E again, back to the standard mode.
<b>FN + R</b> Onboard mode3 Layer3 / Fn3	 FN + R, onboard mode layer3, "R" lights white LED. The reference Setting: Some special function keys, or combination keys, or macro keys, these settings of this mode can be called by the key FN3 in layer1&layer2. All Settings in this mode can be modified and saved to the keyboard. Press FN+R again, back to the standard mode.


**More function and LED backlight settings, please download or update the driver from the following website:** <http://www.Jikedingzhi.com/downloadlist?driverID=41>

## FAQ

- **Q:** How do I clean Product XYZ?
  - **A:** To clean Product XYZ, follow these steps:
    - Unplug the product from the power source.
    - Use a damp cloth with mild soap to wipe down the surfaces.
    - Avoid using harsh chemicals or abrasive materials to prevent damage.
- **Q:** Can Product XYZ be used outdoors?
  - **A:** No, Product XYZ is designed for indoor use only. Using it outdoors may damage the product and void

the warranty.

## Documents / Resources

	<p><a href="#">EPOMAKER SK71 Keys Hot Swappable Mechanical Keyboard</a> [pdf] User Manual SK71 Keys Hot Swappable Mechanical Keyboard, SK71, Keys Hot Swappable Mechanical Keyboard, Swappable Mechanical Keyboard, Mechanical Keyboard</p>
---	---

## References

- [📁 Your Ultimate Resource for Millions of User Manuals](#)
- [User Manual](#)

### Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.