


# **EPSON DS-530 II Color Duplex Document Scanner User Guide**

Home » Epson » EPSON DS-530 II Color Duplex Document Scanner User Guide 🖫


**EPSON DS-530 II Color Duplex Document Scanner** 



### **Contents**


- 1 Package Content
- 2 Remove The Packing
- 3 Turn On The Scanner
- **4 Install Software**
- **5 Scan A Document**
- 6 Scan From A Mobile Device (DS-575W II)
- **7 Scan From A Computer**
- 8 Troubleshooting Wi-Fi Setup(DS-575W
- II)
- 9 Help
  - 9.1 Scanner software help
  - 9.2 User's Guide
  - 9.3 Epson technical support
- 10 Documents / Resources
  - 10.1 References
- 11 Related Posts


# **Package Content**




Note: Do not connect the USB cable until instructed to do so.

# **Remove The Packing**





Press the Opower button.



### **Install Software**

Note: An internet connection is required to obtain the product software

- 1. Visit Epson's support site listed below for your model
  - DS-530 II (U.S./É.-U.)

www.epson.com/support/ds530II

DS-530 II (Canada)

www.epson.ca/support/ds530II

• DS-575W II (U.S./É.-U.)

www.epson.com/support/ds575wll

DS-575W II (Canada)

www.epson.ca/support/ds575wll

• DS-770 II (U.S./É.-U.)

www.epson.com/support/ds770II

DS-770 II (Canada)

www.epson.ca/support/ds770II

- 2. Click **Download** for the Drivers and Utilities Combo Package.
- 3. Double-click the file you downloaded to install the software. Follow the on-screen instructions to set up the connection.





# Scan A Document

Note: To scan using the start button, you must connect the scanner to a computer with Document Capture Pro (Windows®) or Document Capture (Mac) installed.




Load the document facedown, short edge first.





Press the start button

Document Capture Pro (Windows) or Document Capture (Mac) starts automatically and your document is scanned.



Note: For detailed information on loading and scanning originals, see the online User's Guide.



# Scan From A Mobile Device (DS-575W II)



To scan from an iOS or Android™ device, download and install the free Epson Smart Panel app from the App Store or Google Play™.



# **Scan From A Computer**

You can also scan from your computer with Document Capture Pro (Windows) or Document Capture (Mac).

Windows 10: Click > Epson Software > Document Capture Pro.

Windows 8.x: Navigate to the Apps screen and select Document Capture Pro.

Windows 7: Click > All Programs > Epson Software > Document Capture Pro.


Mac: Select Applications > Epson Software > Document Capture.

For more information about scanning from a computer and creating custom scan jobs with Document Capture Pro (Windows) or Document Capture (Mac), click the Help or ? button in the scanner software or see the online *User's Guide.* 



# Troubleshooting Wi-Fi Setup(DS-575W II)

 Your network name (SSID) and password are case sensitive. Make sure you enter uppercase and lowercase letters correctly.



- If the scanner did not connect automatically and you are connecting it to the network manually, make sure you select the same network that the computer is connected to.
- The scanner can only connect to a network that supports 2.4 GHz connections. If your router offers both 2.4 GHz and 5 GHz connections, make sure the 2.4 GHz band is enabled and you are connecting to it.



- If your computer is connected to the 5 GHz band, connect it to the 2.4 GHz band for scanner setup. This will allow the scanner to automatically connect to the network when you repeat the software installation process.
- Turn your router off and on again, then repeat the software installation process.



#### Scanner software help

Click the Help or ? button on your software screen.

#### User's Guide

Double-click the Epson DS Series User's Guide icon on your desktop (or in the Applications/Epson Software/Guide folder on a Mac).

#### **Epson technical support**

### Internet support

Visit <u>www.epson.com/support</u> (U.S.) or <u>www.epson.ca/support</u> (Canada) and search for your product to download software and utilities, view manuals, get FAQs and troubleshooting advice, or contact Epson.

#### Speak to a support representative

Call (562) 276-4300 (U.S.) or (905) 709-3839 (Canada), 6 am to 8 pm, Pacific Time, Monday through Friday, and 7 am to 4 pm, Pacific Time, Saturday.

Days and hours of support are subject to change without prior notice. Toll or long distance charges may apply



EPSON is a registered trademark and EPSON Exceed Your Vision is a registered logomark of Seiko Epson Corporation.

Windows is a registered trademark of Microsoft Corporation in the United States and/or other countries. Mac is a trademark of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android and Google Play are trademarks of Google LLC.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of

their respective owners. Epson disclaims any and all rights in those marks. This information is subject to change without notice.



CPD-59607 © 2020 Epson America, Inc., 7/20

#### **Documents / Resources**



**EPSON DS-530 II Color Duplex Document Scanner** [pdf] User Guide DS-530 II, DS-575W II, DS-770 II, DS-530 II Color Duplex Document Scanner, Color Duplex Document Scanner, Document Scanner

## References

- E Epson® Official Support
- E Epson DS-530 II | DS Series | Scanners | Support | Epson Canada
- E Epson DS-575W II | DS Series | Scanners | Support | Epson Canada
- E Epson DS-770 II | DS Series | Scanners | Support | Epson Canada
- E Epson® Official Support
- E Epson DS-530 II | DS Series | Scanners | Support | Epson US
- E Epson DS-575W II | DS Series | Scanners | Support | Epson US
- E Epson DS-770 II | DS Series | Scanners | Support | Epson US

Manuals+,