

EPSON Master Device



Contents [[hide](#)]

- [1 Master Device](#)
- [2 Overview](#)
- [3 How To Select The Master Device](#)
- [4 Appendix: Menu Routing Diagrams](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)

Master Device

About this guide:

This guide consists of 3 sections:

- **Overview** – Describes the Master Device selection in a True Order™ Kitchen Display System (KDS).
- **How to Select the Master Device** – A procedure to be followed to select Master Device within a Multi-Station KDS Setup.
- **Appendix** – System diagrams for KDS and POS menu routing.

Overview

Every True Order KDS must have one device designated as the Master, POS Attached Device. In systems with just one device the choice is automatic and there is nothing to configure. In multi-station systems that have more than 1 device one needs to be designated as the Master, POS Attached Device. Which one to configure depends on your multi-station routing method:


- **KDS Menu Routing** – All print jobs are sent directly to a main device. The menu configuration and routing determine which stations items in an order are sent to. This device needs to be the Master, POS Attached Device.
- **POS Menu Routing** – All print jobs are sent from the POS directly to their intended display stations. The POS determines which items are sent where and all menu management remains on the POS. Any device can be designated as the Master, POS Attached Device.

EPSON is a registered trademark and EPSON is a registered logo mark of Seiko Epson Corporation. All other product and brand names are trademarks and/or registered trademarks of their respective companies. Epson disclaims any and all rights in these marks.

Copyright 2025 Seiko Epson Corporation.

How To Select The Master Device

1. Click **“APPLICATION SETTINGS”** -> **“SITE WIDE”**, select Master Device from **“POS Connected Device”** drop-down list, and select POS parser from **“POS Type”** drop-down.



IMPORTANT: The POS parser gets installed on the selected POS Connected device and is different for each hardware model. By default, every device ships with a full list of parsers built for itself. The parser name and corresponding IPK filename have the hardware variant in them. For example, in the above picture the POS Type “Epson KDS mtmc Version 3.4” contains “mtmc”, which means Micro Touch Mach platform. Below is the list of supported hardware platforms for each hardware variant.

Supported hardware platforms for POS parsers with name mtic:

- **Micro Touch AIO 21.5” Touchscreen Part#:** IC-215P-AA2-A016
- **Micro Touch Media Player Part#:** MP-000-AA2-A017

Supported hardware platforms for POS parsers with name ls89:

- **Logic Controls Controller Part#:** LS8900-Epson

Supported hardware platforms for POS parsers with name eloi:

- **ELO AIO 21.5” Touchscreen Part#:** E166526
- **ELO Backpack Part#:** E166712

Supported hardware platforms for POS parsers with name mtmc:

- Micro Touch All-In-One Touchscreens Part#:
 - M1-215IC-AA2-A037 M1-215IC-AA3-A038 (Po E)
 - M1-156IC-AA2-A040 M1-156IC-AA3-A041 (Po E)
- Micro Touch Mach Media Player Part#:
 - M1-MP-AA2-A039

2. Click **“PUBLISH”** to apply setting.

KDS Configuration Utility
STATIONS
LAYOUT
MENU & RECIPES
APPLICATION SETTINGS
PUBLISH
E

Application Settings

Application Properties and Settings

SITE WIDE
WIZARD
DISPLAY LOGOS

Site wide

Define settings for the application

RESTORE
SAVE

CONFIGURATION

Name
Site Name

POS Type
EpsonKDS Version 3.2

POS Connected Device
Kitchen

Menu Routing
POS Menu Routing


Daily Maintenance Time
07:00 AM

☐ Consider Orders Unique


☐ Independent Displays

Appendix: Menu Routing Diagrams

KDS Menu Routing



POS Menu Routing



Master Device Quick User Manual

111-56-QUM-023 Rev 3.36

EPSON®

Documents / Resources

	EPSON Master Device [pdf] User Guide Master Device, Master, Device
--	---

References

- [User Manual](#)

Epson
 device, Epson, MASTER, Master Device

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.