




eQuation CH505FT Convector Instruction Manual

[Home](#) » [equation](#) » eQuation CH505FT Convector Instruction Manual 





**Assembly – Use – Maintenance Manual
2 YEAR GUARANTEE**

This product is only suitable for well insulated spaces or occasional use.

Contents


- 1 CH505FT Convector
- 2 SAFETY REQUIREMENTS FOR ALL PORTABLE HEATERS
- 3 INSTALLATION
- 4 HOW TO USE
- 5 CLEANING & MAINTENANCE
- 6 DISPOSAL AND RECYCLING
- 7 Information requirements for electric local space heaters
- 8 Assembly
- 9 Documents / Resources

CH505FT Convector

**CH505FT
Original Instructions**




0 1 2 3 4 5 cm




D x4
M4 x 12mm





B x2




C x1



A x1



	Caution danger
	Connected
	Power off
	Power Up
	Correct
	Incorreacl

SAFETY REQUIREMENTS FOR ALL PORTABLE HEATERS

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision. Children of less than 3 years should be kept away unless continuously supervised.

- Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
- **CAUTION** — Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- **CAUTION:** In order to avoid a hazard due to inadvertent resetting of the thermal cutout, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.
- **WARNING:** In order to avoid overheating, do not cover the heater.
- The heater must not be located immediately below a socket-outlet.



- Do not use this heater in the immediate surroundings of a bath, a shower
- The heater must not be located immediately below a socket-outlet.
- Do not use this heater in the immediate surroundings of a bath, a shower

INSTALLATION

- **WARNING:** Your heater shall be used as portable appliance only(thanks to respect all the safety warnings given below).
Move the heater only by its handles.Never move the heater when it's working. Never let the heater under the rain or under wet conditions.
Put the heater only on plane, clean & empty surface.
- **WARNING:** Let a minimum distance of 1m between any side of your appliance and any obstacle (furniture or walls, for example)
- **WARNING:** Always use your appliance with rollers or feet fixed.
- **THIS PRODUCT IS FOR ROOM HEATING**

HOW TO USE

- Plug the appliance to a 220-240V 50-60Hz socket. If you are not sure, we advice you to contact a professional electrician for more details.
- To start the heater, choose power I / II //.
- Set the temperature with the thermostat.
- To stop the heater, put the switch on the position symbolized by "0".
- Unplug the product when it's not in use.

CLEANING & MAINTENANCE

- Switch off and unplug from the power supply before cleaning.
- Using a soft, moist cloth, with or without a mild soap solution, carefully clean the exterior surface of the product.
- **CAUTION:** Allow the product to completely cool before handling or cleaning it.
- Do not allow water or other liquids to run into the interior of the product, as this could create a fire and/or electrical hazard.
- We also recommend the periodic cleaning of this appliance by lightly running a vacuum cleaner nozzle over the guards to remove any dust or dirt that may have accumulated inside or on the unit.
- **CAUTION:** Do not use harsh detergents, chemical cleaners or solvents as they may damage the surface finish of the plastic components.

DISPOSAL AND RECYCLING

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. T hey can take this product for environmental safe recycling.




CH505FT
220-240V 50-60Hz

Information requirements for electric local space heaters


Model identifier(s): CHSO5FT					
Item	Symbol	Value	Unit	Item	Unit
Heat output				Type of heat input, for electric storage local space heaters only (select one)	
Nominal heat output	P _{nom}	1,9	kW	manual heat charge control, with integrated thermostat	(no)
Minimum heat output (indicative)	P _{min}	0	kW	manual heat charge control with room and/or outdoor temperature feedback	Inol
Maximum continuous heat output	P _{room}	1,9	kW	electronic heat charge control with room and/or outdoor temperature feedback	(no)
Auxiliary electricity consumption				fan assisted heat output	Inol
At nominal heat output	el _{ti}	0	kW	Type of heat output/room temperature control (select one)	
At minimum heat output	el _l	0	kW	single stage heat output and no room temperature control	(no)
In standby mode	el _{sr}	0	kW	Two or more manual stages, no room temperature control	(no)
				with mechanic thermostat room temperature control	Eyes)
				with electronic room temperature control	(no)
				electronic room temperature control plus day timer	(no)
				electronic room temperature control plus week timer	(no)
				Other control options (multiple selections possible)	
				room temperature control, with presence detection	(no)
				room temperature control, with open window detection	(no)
				with distance control option	(no)
				with adaptive start control	Inol
				with working time limitation	Inol
				with black bulb sensor	Inol
Contact details	ADEO Services 135 Rue Sadi Carnot – CS00001 59790 RONCHIN – France				

Assembly







3




Use


1.a




1.b



2



3



STOP



1250W +



2000W +



1250W



2000W










0-3 H



STOP




ON





15 min.

3




6.a




6.b



4




5



Winter storage

1






CE



Made in China 2022

Documents / Resources

	<p>eQuation CH505FT Convector [pdf] Instruction Manual CH505FT Convector, CH505FT, Convector</p>
---	--