

ERAY®

H2 Karaoke Magic Color Digital Player



ERAY H2 Karaoke Magic Color Digital Player User Manual

[Home](#) » [ERAY](#) » ERAY H2 Karaoke Magic Color Digital Player User Manual 

Contents

- 1 ERAY H2 Karaoke Magic Color Digital Player
- 2 Warm reminder
- 3 Function introduction
- 4 Player technical indicator
- 5 Microphone function introduction
- 6 Mobile phone Bluetooth connection method
- 7 Product Accessories
- 8 Documents / Resources
 - 8.1 References



ERAY H2 Karaoke Magic Color Digital Player






Welcome to buy this product



- Thank you for choosing to buy the H2 Karaoke (magic color) digital player.
- This product adopts advanced technology in the industry and has strong compatibility.
- You can easily enjoy the fun of mobile Karaoke (magic color) and experience the feeling of KTV anytime, anywhere only by connecting the audio playback device.
- I hope that you will have a pleasant feeling of using it.

Warm reminder

Safety requirements	Please read this manual carefully before use.
	Please use this product at room temperature.
	Please select a charger that complies with safety regulations to charge.
	If you do not use it for a long time, please charge it once within 1 month.
	Please do not expose this product to the sun or near the stove, where the temperature is too high, there is a lot of dust, and there are many corrosive gases.
	Please do not hit or drop this product. If it is damaged, please do not disassemble it yourself.
	When the outside is dirty, wipe it with a clean soft cloth, but pay attention to the water stains of the soft cloth to avoid damage caused by flowing into the inside of the product.

Function introduction


1. Switch button
2. AUX external input port (3.5mm audio cable)
3. Type-c charging interface
4. TF memory card interface
5. USB memory interface
6. key: short press to switch the playback mode (Bluetooth, USB, TF, AUX).
7.  Key: short press to play the previous song (there is no such function in AUX mode), long press the volume to reduce.
8.  Key: short press play/pause.
9.  Key: short press to play the next song (this function is not available in AUX mode), long press volume plus.
10. Indicator light: Bluetooth/charging indicator light, blue light/red light.



Player technical indicator

Bluetooth version	Version 5.0
Charge input	DC5V-2A
Speaker	66mm
Signal-to-noise ratio	≥75d B
Player Battery	18650 3.7V 1200mAh
Bluetooth connection distance	>10 meters (accessible)

Microphone function introduction



Microphone technical indicators

Microphone type	Condenser microphone
Charge input	DC5V-2A
Connection method	2.4G 30Hz-16KHz
Low latency	Latency less than 40ms
Microphone battery	14500 3.7V 500mAh
Effective connection distance	10 meters accessible

Mobile phone Bluetooth connection method

1. Turn on the power button and short-press the M key to switch to Bluetooth mode.
2. Turn on the Bluetooth of the mobile phone, search for the device name (H2) of the local machine, and click Connect to pair.
3. Open the music software on your mobile phone and click on your favorite music to enjoy.


USB/TF card play

1. Insert the USB/TF card with music files into the corresponding card slot to play.
2. Support MP3 format and some lossless formats.

AUX(external sound source input)

- This machine is available 3.5mm audio cable external mobile phone,
- DVD player, TV, MP3/4 player equipment.


Product Accessories



Player



Microphone



Type-C charging cable




Manual

After-sales Email: service@erayvip.com

Thank you for purchasing our product, please read the user manual before use and keep it properly for future reference.

Documents / Resources

	<p>ERAY H2 Karaoke Magic Color Digital Player [pdf] User Manual</p> <p>H2 Karaoke Magic Color Digital Player, H2, Karaoke Magic Color Digital Player, Magic Color Digital Player, Color Digital Player, Digital Player, Player</p>
---	--

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.