Eseecloud Remote View Setup App









Eseecloud Remote View Setup App User Guide


Home » EseeCloud » Eseecloud Remote View Setup App User Guide The Company of the

Contents

- 1 Eseecloud Remote View Setup
- 2 Product Information
- 3 Product Usage Instructions
- **4 Remote View Setup**
- **5 Install Esectoud App**
- **6 Create Account**
- **7 Account Verification**
- **8 Add New Device**
- 9 Complete Setup
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts



Eseecloud Remote View Setup App











Product Information

Specifications:

• Product Name: Security Camera System

· App Name: Eseecloud

 Compatibility: Smartphone and Tablet · Connection: Ethernet cable or Wi-Fi

Product Usage Instructions

Remote View Setup:

1. Install Eseecloud App:

- 1. Download: Visit the App Store or Google Play Store to download the Eseecloud App on your smartphone or tablet.
- 2. Installation: Follow the on-screen instructions to complete the installation process after downloading.
- 3. **Login:** Create an account using your details once the app is installed.

2. Create Account:

- 1. Enter Details: Provide your phone number or email, set up a password, and fill out the necessary registration information.
- 2. Verification: A verification code will be sent to you for account verification.

3. Add New Device:

- 1. Select Option: Choose the 'Add camera' option after logging in.
- 2. **Device Cloud ID:** Enter the unique Cloud ID from your NVR system.
- 3. Three Options for Adding a New Device:
 - 1. Scan to Add: Scan the QR code shown on your NVR screen.

- 2. Camera ID Add: Manually input the Cloud ID if necessary.
- 3. LAN Scan: Select 'LAN Scan' to search for local devices.

4. Complete Setup:

1. **Final Review:** Ensure NVRs are connected to your home router and operating correctly. Click the play button in the app for remote monitoring.

FAQ

Q: What do I do if I don't receive the verification code?

A: Check your text messages or email inbox, including the spam folder, for the verification code. If you still don't receive it, contact customer support for assistance.

Remote View Setup

To set up remote viewing, you need to install the Eseecloud App and register an account. This allows you to access live feeds from your security cameras from anywhere.



Install Esectloud App

1. Download

Visit the App Store or Google Play Store to download the Eseecloud App on your smartphone or tablet.

2. Installation

After downloading, follow the on-screen instructions to complete the installation process.

3. Login

Once installed, create an account using your details.




Create Account

Create Account

Enter your phone number or Email, set up a password, and fill out the necessary registration information.

Verification

Verification Code will be sent to you.




Account Verification

1. Verification Code

Check your text messages or email inbox (including the spam folder) for a verification code, and enter the code or click on the link to verify your account.

2. Complete Setup

Once verified, you'll be directed to complete your account setup within the Eseecloud App.




Add New Device

· Add new device

After logging in, select the '+' sign or choose the 'Add camera' option.


• Device Cloud ID

Enter the unique Cloud ID, which can be located in your NVR system under 'System Setting > Network' (Old UI) or 'System Setup > App/account' (New UI).




Click "Cancel"

** Skip this step if you are an iPhone user.




Swipe up on the screen to view more options



There are three options for adding a new device

Scan to add, Camera ID add, LAN scan




1. Scan to Add

QR Code

Scan the QR code shown on your NVR screen, which can be found within your NVR system under 'System Setting > Network' (Old UI) or 'System Setup > App/account' (New UI).


If scanning is not possible due to screen glare, please use another option to add your device.



2. Camera ID add

1. Manual Entry

If necessary, manually input the Cloud ID to connect the device to the app. Use your NVR User name and password The username and password will be the same as those used for your NVR.




3. LAN scan

1. Access LAN Settings

Within the options, select 'LAN Scan' to search for your local device.

2. Device List

After scanning, a list of local devices will appear. Select the ones you wish to add.




Complete Setup

1. Final Review

Ensure that all your NVRs are correctly connected to your home router via Ethernet cable or Wi-Fi and are operating as expected.

2. Remote View

To begin remote monitoring of your cameras, just click the play button in your app.



Documents / Resources



Eseecloud Remote View Setup App [pdf] User Guide Remote View Setup App, Remote, View Setup App, Setup App, App

References

- **Gamma**
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.