

ESORUN DECK-TS 3 In 1 Desktop Wireless Charger User Manual

Home » ESORUN » ESORUN DECK-TS 3 In 1 Desktop Wireless Charger User Manual



Contents

- 1 ESORUN DECK-TS 3 In 1 Desktop Wireless Charger
- **2 SPECIFICATIONS**
- **3 PRODUCT STRUCTURE**
- 4 HOW TO USE?
- 5 Charging mobile device from wireless transmitter
 - 5.1 Phone
 - 5.2 Apple Watch
 - 5.3 AirPods
- **6 Correct Position Reference**
- 7 LED Usage
- **8 REMARKS**
 - 8.1 Magnets
 - 8.2 Credit Cards
 - 8.3 Metal Cases
 - 8.4 When your wireless charging is not working properly
- 9 Documents / Resources
- **10 Related Posts**




ESORUN DECK-TS 3 In 1 Desktop Wireless Charger



SPECIFICATIONS

- Watch Output:3W Max Apple Watch Seriesl,2,3,4,5
- Airpods Output: 5WMax AppleAirpod2,3 Input: 5V/3A, 9V/2A, 12V/2A
- Adapter Requirements: QC2 0/3 0/PD Fast Adapter
- Charging Efficiency:75
- Charging Distance:6m
- Dimension: 6.0'6 0'0.55 inc
- Weight: 6.41oz 182g


PRODUCT STRUCTURE



second charging area indicator lamp.

HOW TO USE?


Connect the charging cradle to the wall adapter.




Charging mobile device from wireless transmitter

Place your mobile devices in the corresponding charging position of the product (device must support wireless charging.

Phone




Apple Watch






Correct Position Reference



LED Usage



REMARKS

- 1. Quick charge QC2.0/ QC3.0/QC4.0/PD Fast Charger wall adapter required to access fast wireless charging.
- 2. To ensure proper use, please use our USB-Type C cable included.
- 3. It is normal for the wireless charger and your smartphone to get hot under working conditions 1 especially when the phone is being charged and used at the same time such as playing music
- 4. Not works with 5V/1A or lower input such as PC powered or USB port from socket.

Attention

Not for SAMSUNG Watch and Only supportsAirPods with wireless charging cases.


Magnets



Credit Cards



Metal Cases



When your wireless charging is not working properly

- Clean the clutter on the wireless charge.
- Please make sure the wireless charging coil is correctly positioned with the phone coil transmitter.
- Please wait for the wireless transmitter to cool down before trying to charge it.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measure

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution

Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

Documents / Resources



ESORUN DECK-TS 3 In 1 Desktop Wireless Charger [pdf] User Manual DECK-TS, DECKTS, 2AP2N-DECK-TS, 2AP2NDECKTS, 3 In 1 Desktop Wireless Charger, DE CK-TS 3 In 1 Desktop Wireless Charger

Manuals+,