

ESR B09N744Y4C ASCEND Keyboard Case User Guide

Home » ESR » ESR B09N744Y4C ASCEND Keyboard Case User Guide 🖔



Contents

- 1 User Manual
- 2 Shortcut Keys
- **3 Troubleshooting Guice**
- 4 Documents /
- **Resources**
- **5 Related Posts**

User Manual

Pairing Mode Hold for 4 for 3 seconds to enter pairing mode, If not connected after 3 minutes, pairing mode will turn off.

Auto Reconnect When turned on, the keyboard will automatically attempt to reconnect with the last paired device for 5 seconds.

Power Light Charging:

Overview Fully charged:

Low battery: • 1


Power Key Press Press once to tum on the keyboard. Hold for 3 seconds to turn off the keyboard. Standby Mode The keyboard backlight will turn off automatically after 1 minute of inactivity. After 10 minutes of inactivity, the keyboard will enter standby mode. Press any key to wake the keyboard.

Backlight Press to select the backlight brightness (bright, medium, low, off). Press to select the backlight color (7 colors).

Factory Reset Press and hold + for 3 seconds.

The caps lock and power light will flash to indicate the factory reset is complete.

Shortcut Keys



Troubleshooting Guice

If the keyboard stops working, please check the following:

- 1. Ensure the keyboard is turned on.
- 2. If the keyboard is out of battery, charge the keyboard.
- 3. If the connection is unstable, turn the keyboard off and wait 10 seconds before turning it back on. If the problem persists, disconnect the keyboard by going to Settings > Bluetooth > Device List > "ESR KEYBOARD" and tap then choose "Forget This Device. Follow the Bluetooth pairing instructions to reconnect your keyboard. If the keyboard remains unresponsive, repeat the above steps.

If you are still experiencing problems, con. ct our customer service at esrgear.com/contact-us/

Reminder

This Bluetooth keyboard has a rechargeable battery. When not using the keyboard for an extended period of time, turn the keyboard off by holding El for 3 seconds to prolong battery life.

Documents / Resources



ESR B09N744Y4C ASCEND Keyboard Case [pdf] User Guide 6B005, 2APEW-6B005, 2APEW6B005, B09N744Y4C, ASCEND Keyboard Case, B09N744Y4C ASCEND Keyboard Case, Keyboard Case, Case

Manuals+,