



Eugeria T30 Idem Smart Display User Manual

[Home](#) » [Eugeria](#) » Eugeria T30 Idem Smart Display User Manual 

Eugeria

Idem Smart Display
User's Manual
(Multi-Language)
Tablet Pc

WELCOME TO USE VEIDOO PAD

Contents

- [1 Button Introduce:](#)
- [2 Android System](#)
- [3 Install the APK Application:](#)
- [4 Matters need attention:](#)
- [5 Documents / Resources](#)
- [5.1 References](#)

Button Introduce:

1. Power Button—Turn on/Turn of your tablet.
2. Volumn+/Volumn -: Adjust the volumn of your tablet.
3. Type-C Charger—While charging, the device may heat up. This is normal and should not affect your device 's lifespan or performance.
4. SD/SIM Card slot—Insert the Nano-SIM card into the slot to use 3G/4G wireless network, Insert your TF card into the slot and you can expand the storage of the tablet.
5. Reset slot—Near the Power button and you can plug a card spin into the reset hole.
6. Headphone Connector —You can use your earphone after connecting the earphone hole .

Android System

I Interface—When the Android operating system starts, the startup interface will be displayed.

II Control Center—Swipe down from the upper -right corner to change volume, brightness, wireless settings, and more, and select available WiFi to connect.

III Language—This tablet has over 100 kinds of languages, and you can switch to the language you need. You can click Settings and re-select the language.

IV App Switcher—Click the small square button at the bottom right corner of the screen and switch between recent apps.

V Top Button—Press once to sleep or wake.

Install the APK Application:

1. Make sure the device was connected WiFi. Tap “Google Play” to search the APK format application you want to install.
2. Download the APK format application.

Matters need attention:

1. Do not use it when charging to ensure battery life.
2. Please regularly remove unused software to keep the tablet PC running at high speed.
3. Do not disconnect while the product is under formatting. uploading or downloading operations, otherwise there may be system errors or dead device.
4. When the tablet freezes or has a black screen, it is recommended that you use a card pin to poke the reset hole on the side of the tablet. The reset button on the tablet is right next to the power button.
5. Always drop your used electronic products, batteries, and packaging materials after the end of their life in nearest collection point or collection center. Separate the packaging material according to responsible waste disposal options and sorting for recycling.

Contact Us:

Customer Service Email: support@veidoo.com

Manufacturer: Shenzhen Veidoo Digital Vision Co., Ltd

Address: 4th Floor, Block 6, Saitu Technology Park, No. 137 Bulan Road, Jihua Street, Longgang District, Shenzhen, China.518100

EC | REP

Name der firma: SINO-SEAR GmbH

Adresse: Feuerbachstrasse11, 14471 Potsdam,
Germany

Tel: +49 331 9513 0908

Email; info@sino-sear.com

UK | REP

Company Name: REPLAB COI

Adresse: 28 BARLETTA HOUSE
CARDIFF, WALES, CF10 4AF

Tel: +44 29 2255 0988

Email: UKREP@REPLAB.CO

WARNING: CHOKING HAZARD — Small parts. Not for children under 3 yrs.



Documents / Resources

	<p>Eugeria T30 Idem Smart Display [pdf] User Manual T30 Idem Smart Display, T30, Idem Smart Display, Smart Display</p>
---	--

References

- [User Manual](#)