evil CONTROLLERS X1IBUCXMM Master Mod V3 Wireless Controller for Xbox One Instruction Manual

evil CONTROLLERS X1IBUCXMM Master Mod

V3 Wireless Controller for Xbox One

Instruction Manual

https://www.youtube.com/playlist?list=PLRYYbSxfUiOkNlpueCmM8Y5SdsdXUJbst

Contents [**hide**]

1 ABOUT PROFILES

Your Evil Controller comes with 20 customizable profiles.
They operate just like c lasses in Call of Duty@ Simply select the profile (class) and assign mods (perks).

By default, t he first 10 profiles have a fire rate equal to that of their profile number. For exam p le, profile 5 = 5 shots per second . Learn how to modify these defaults under **ADJUSTABLE RAPID FIRE.**

UPON PROFILE ACTIVATION, PROFILE 1 WILL AUTOMATICALLY BE SELECTED.

20 CUSTOMIZABLE PROFILES

| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |

DEFAULT FIRE RATES

2 SELECT/CLEAR PROFILE

SELECT A PROFILE

Tap X (profile#) of times to choose desired profile. For example, tapping X 5 times= profile 5.

✚ + ⊗ × **PROFILE#** | Hold for 2 seconds.
(HOLD)   (HOLD)

CLEAR ALL

Forgot what mods are on? Clear all in current profile.

✚ + Ⓑ | Hold for 2 seconds.
(HOLD)   (HOLD)

3 PROGRAMMING MODS

RAPID FIRE

➕ + RT

(HOLD)   (PULL)

See **Advanced Mods** for adjusting rate of fire.

LEFT TRIGGER RAPID FIRE

➕ + LT

(HOLD)   (PULL)

AKIMBO RAPID FIRE

LT + RT + ➕

(HOLD)   (HOLD)   (TAP)

TACTICAL RAPID FIRE

① Activate mod.
Pressing **Y** to swap weapons
will toggle Rapid Fire on/off.

➕ + Y

(HOLD)   (TAP)

② Toggle Rapid Fire on/off
without switching weapons.

Y   Y

(DOUBLE TAP)

③ Return to standard Rapid Fire.

➕ + RT

(HOLD)   (PULL)

DROP SHOT

Default button layout:

HOLD + B TAP

Press **A** to stand up and keep Drop Shot active.

Press **B** to stand up and deactivate Drop Shot.

Tactical button layout:

HOLD + RS CLICK

Press **A** to stand up and keep Drop Shot active.

Press **RS** to stand up and deactivate Drop Shot.

AUTO SCOPE/ AUTO RUN

HOLD + LS CLICK

To enable Auto Run, tap LT while moving.

AUTO SPOT

AUTO SPOT
Battlefield 4® Only

HOLD + RB CLICK

Auto spot must be toggled off when in menu, otherwise the controller cycles through classes.

4 ADVANCED MODS

ADJUSTING RATE OF FIRE

[HOLD] + RT [PULL] | Hold for 2 seconds.

It's possible for the rate of fire to be so fast that it doesn't register in-game. Slowing automatic weapons down to reduce recoil and increase accuracy can be effective. Features 15,000 speed increments.

= Increase rate of fire.

= Decrease rate of fire.

TAP to increase by one step. HOLD to increase continuously.

= Lock rate of fire.

EVIL RAPID FIRE INCREMENTS

(+)

TOO FAST
Weapon stutters/won't fire

GOAL

PERFECT
Ideal fire rate for selected weapon

(I)

TOO SLOW
Weapon fires too slowly

FAST RELOAD

Call of Duty: Ghosts

Call of Duty: Modern Warfare

Functions like the Sleight of Hand perk, but does not animate in a similar manner. Because weapons reload at different rates, Fast Reload must be programmed and adjusted accordingly.

1. Equip your gun of choice.
2. Fire off a few rounds.
3. Press and hold d-pad down and X to reload.
4. Released-pad down and X when the bullet counter shows a full magazine.
5. Fire off a few more rounds.
6. Test the reload by tapping X.
7. Hold RT after tapping X and your gun will immediately fire once the Fast Reload is complete. The animation may appear "glitchy", but that's just the mod cutting away the unnecessary animation.

Note Holding d-pad down and X will restart the programming process.

JITTERMOD (AUTO BURST)
Call of Duty: MWR Only (M76A4)

Enter a profile then,

Activating jitter will disable Rapid fire. Repeat function to disable jitter and reactivate Rapid Fire.

HOW-TO VIDEOS ON
TINYURL.COM/EVIL-PLAYLIST

TINYURL.COM/EVIL-PLAYLIST

5 PROFILE FEATURES

CHECK PROFILE #

Check current profile number. Pulse/Rumble indicates profile

TOGGLE PROFILES ON/OFF

Quickly return controller to stock functionality.

LOCK

Prevent mods from being turned on/off during game play.

Hold for 3 seconds. When LED pulses, release.

MASTER RESET

Restore the controller to factory settings. Do not perform this operation unless you want to overwrite all o f your customized profiles.
This action cannot be undone.

Note. Mods must be toggled off in order to perform Master Reset .

Hold for 10 seconds

HOW-TO VIDEOS ON TINYURL.COM/EVIL-PLAYLIST

Documents / Resources

	evil CONTROLLERS X1IBUCXMM Master Mod V3 Wireless Controller for Xbox One [pdf] Instruction Manual X1IBUCXMM, Master Mod V3 Wireless Controller for Xbox One