

evil CONTROLLERS XBOX Series X Master Mod Remote Controller Instruction Manual

<u>Home</u> » <u>evil CONTROLLERS</u> » evil CONTROLLERS XBOX Series X Master Mod Remote Controller Instruction Manual





INSTRUCTION MANUAL



https://www.youtube.com/playlist?list=PLRYYbSxfUiOkNIpueCmM8Y5SdsdXUJbst

Contents [hide 1 ABOUT PROFILES 2 SELECT/CLEAR PROFILE 3 PROGRAMMING MODS 4 ADVANCED MODS 5 PROFILE FEATURES 6 Documents / Resources 7 Related Posts

ABOUT PROFILES

Your Evil Controller comes with 20 customizable profiles. They operate just like classes in Call of Duty® Simply select the profile (class) and assign mods (perks).

By default, the first 10 profiles have a fire rate equal to that of their profile number. For example, profile 5 = 5 shots per second. Learn how to modify these defaults under **ADJUSTABLE RAPID FIRE**.

UPON PROFILE ACTIVATION, PROFILE 1 WILL AUTOMATICALLY BE SELECTED.



SELECT/CLEAR PROFILE

SELECT A PROFILE

Tap X (profile #) of times to choose the desired profile. For example, tapping X 5 times = profile 5.



CLEAR ALL

Forgot what mods are on? Clear all in the current profile.



PROGRAMMING MODS



TACTICAL RAPID FIRE

1)Activate mod. Pressing Y to swap weapons will toggle Rapid Fire on/off.



2) Toggle Rapid Fire on/off \—" without switching weapons.



3) Return to standard Rapid Fire.



DROP SHOT Default button layout:



Press A to stand up and keep Drop Shot active. Press B to stand up and deactivate Drop Shot.

Tactical button layout:



Press A to stand up and keep Drop Shot active. Press RS to stand up and deactivate Drop Shot.

AUTO SCOPE / AUTORUN

To enable Auto Run, tap LT while moving.



AUTO SPOT

Auto spot must be toggled off when in the menu, otherwise the controller cycles through classes.




ADVANCED MODS

ADJUSTING RATE OF FIRE



It's possible for the rate of fire to be so fast that it doesn't register in-game. Slowing automatic weapons down to reduce recoil and increase accuracy can be effective. Features 15,000 speed increments.



FAST RELOAD

Call of Duty: Ghosts

Call of Duty: Modern Warfare

Functions like the Sleight of Hand perk but does not animate in a similar manner. Because weapons reload at different rates, Fast Reload must be programmed and adjusted accordingly.




- 1. Equip your gun of choice.
- 2. Fire off a few rounds. 0 Press and hold the d-pad down and X to reload.
- 3. Release the d-pad down and X when the bullet counter shows a full magazine.
- 4. Fire off a few more rounds. ® Test the reload by tapping X.
- 5. Hold RT after tapping X and your gun will immediately fire once the Fast Reload is complete. The animation may appear "glitchy", but that's just the mod cutting away the unnecessary animation.

Note. Holding d-pad down and X will restart the programming process.

JITTERMOD (AUTO BURST)

Call of Duty: MWR Only (M16A4)

Enter a profile then,



Activating jitter will disable Rapid fire. Repeat function to disable jitter and reactivate Rapid Fire.



PROFILE FEATURES

CHECK PROFILE #

Check current profile number. Pulse/Rumble indicates profile. For example, 5 pulses/rumbles = profile 5.



TOGGLE PROFILES ON/OFF

Quickly return controller to stock functionality.



LOCK

Prevent mods from being turned on/off during gameplay. Hold for 3 seconds. When LED pulses, release.



MASTER RESET

Restore the controller to factory settings. Do not perform this operation unless you want to overwrite all of your customized profiles.

This action cannot be undone.

Note: Mods must be toggled off in order to perform Master Reset.

Hold for 10 seconds



HOW-TO VIDEOS ON TINYURL.COM/EVIL-PLAYLIST



Documents / Resources



Manuals+, home privacy