



EXIT TOYS EXIT Tempo 2400 Soccer Goal Instruction Manual

[Home](#) » [EXIT TOYS](#) » EXIT TOYS EXIT Tempo 2400 Soccer Goal Instruction Manual 




EXIT Tempo 2400 Soccer Goal
Instruction Manual




WARNING

CHOKING HAZARD small parts


Adult assembly required retain for future reference




3




4




5



6





Contact Information:

Dutch Toys Group B.V.

Edisonstraat 83

7006 RB Doetinchem, The Netherlands

info@exittoys.com

www.exittoys.com

EXIT Toys is port of:

SIMBA • DICKIE • GROUP

EXIT Toys is a registered trade mark of Dutch Toys Group



www.exittoys.com

MSP-101-V01

Contents

[1 Documents /](#)

[Resources](#)

[2 Related Posts](#)

Documents / Resources

 A product image of the EXIT TOYS Soccer Goal. It shows a white, foldable soccer goal with a black frame and a white net. The EXIT TOYS logo is visible in the top left corner of the image.	EXIT TOYS EXIT Tempo 2400 Soccer Goal [pdf] Instruction Manual EXIT Tempo 2400 Soccer Goal, EXIT Tempo 2400, Soccer Goal, Goal
---	---

Manuals±.