





EXIT TOYS MSP-U009-V01 Scala Aluminum Soccer Goal User Manual

[Home](#) » [EXIT TOYS](#) » EXIT TOYS MSP-U009-V01 Scala Aluminum Soccer Goal User Manual 



Sports goals
User manual



MSP-U009-V01

Contents

- 1 Outdoor fun, games and sports for everyone
- 2 Safe use
- 3 Assembly and installation
- 4 Usage and maintenance
- 5 Warranty
- 6 Documents / Resources
 - 6.1 References

Outdoor fun, games and sports for everyone

Making outdoor toys that everyone can have fun with. It was in this spirit that the founding partners began developing outdoor toys under the name EXIT Toys in 2011. There is one thing we are still sure of: fun comes first! With its unique items, EXIT Toys encourages the whole family to go outside and play together, engage in sports and have lots of fun.

Years of challenging outdoor fun!

The best adventures are had outside; by children, young people and adults alike. At EXIT Toys, we are convinced that good products add to the experience. Because the cooler, better-looking and more challenging the item, the more fun everyone has with it. That's precisely why the design of our products comes first. We are always looking for just that little bit extra.

Safety first

We do everything we can to develop products that are safe for everyone. For us it is a matter of course that our products meet the highest consumer safety standards. Before launching a product on the market, we have independent and expert tests carried out to obtain the necessary certification. We also carry out continuous checks during production and keep abreast of the latest legislative and regulatory developments. You will only find products that meet EXIT Toys' strictest standards in our range.

Do you have a question or comment? We will be happy to help!

We really appreciate you being our customer and thank you for your confidence in EXIT Toys and our products. As we are open to your views, we welcome your comments and ideas. So that we can further improve, develop and expand our products.

Visit the world of EXIT Toys at www.exittoys.com and also discover our other exciting and cool outdoor products that will provide you with years of entertainment. Or simply contact us at info@exittoys.com. We will be happy to provide you with personal advice.

Go Play Outside!

EXIT Toys Team

Safe use

To simplify the assembly, please read the following instructions before beginning.

Keep this manual for future reference.

- Read all instructions and complete all assembly before using.
- This goal is designed to be used for football only and no other purpose.
- This goal can only be used when completely assembled and anchored as written in the instruction.
- Adult assembly required.
- This goal is for outdoor use only.
- This goal is for domestic use as well as for training and competition purpose. (if applicable – see warranty)
- Warning! Choking hazard, small parts. Not for children under 3 years old.
- This product should, at all times, be used by the child under direct supervision of an adult.
- In case the goal is provided with anchoring, ALWAYS ANCHOR GOAL.
- Unsecured Goal can fall over causing serious injury or death.
- Ensure that this goal is secured at all times by means of the appropriate anchoring system for its intended use and when not in use (storage).
- Do not climb, hang or swing on the net or goal frame as this can result in goal falling over causing serious injury or death.
- To reduce risk of entanglement, keep small children away from net area at all times.

- The metal frame of the soccer goal will conduct electricity. Lights, extension cords, and all such electrical equipment must never be allowed to come in contact with the soccer goal.
- Inspect the goal before each use. Make sure the strips and all parts are correctly and securely positioned and attached and check periodically afterwards. Tighten any loose hardware. Replace any worn, defective, or missing parts.
- Wear comfortable clothing free of hooks, snaps, drawstrings or anything which may snag or catch in the soccer goal mesh. Remove jewelry, necklaces, and earrings.
- Do not affix additions/appendages to parts of a goal frame that could affect the essential safety of the goal.

Assembly and installation

The soccer goal is heavy, two able-bodied adults are required to set it up.

- Adequate overhead clearance is essential. Provide clearance for wires, tree limbs, and other possible hazards.
- Lateral clearance is essential. Place the Soccer Goal away from walls, structures, fences, and other play areas. Maintain a clear space on all sides of the soccer goal. A minimum of 3m from frame edge is recommended.
- When moving the assembled soccer goal, have at least two people evenly to the frame to lift the soccer goal off the ground.
- Never set-up the soccer goal in heavy rain, wind or storm conditions, especially storms. It is recommended that the soccer goal be taken apart and stored.
- Place the soccer goal on a level surface before use.
- Secure the soccer goal against unauthorized and unsupervised use.
- ALWAYS anchor the goal, following the assembly instructions. This goal can be installed and anchored on grass, hard ground and artificial grass, see assembly steps.

Usage and maintenance

- Replace damaged and/or broken parts. Make sure that broken or damaged goals cannot be used. Spare parts can be ordered through our website.
- Before each use perform a visual inspection on the following points:
 - o Damage to the goal
 - o Lack of / insufficient anchorage or stability equipment
 - o Damaged or missing fixings
 - o Damaged nets / damaged or missing net fixings
 - o Correct attachment of net to goal frame
- Carry out operational inspections at least every 6 months or at a greater frequency according to national regulations / standards.
- Always record the operational inspection and report any defect.
- Carry out main inspections at least every year or at a greater frequency according to national regulations / standards.
- All inspections should be recorded and reported.

Warranty

1. After the date of the purchase invoice, the owner of the EXIT product has a: Tempo series (domestic use only)
 - 2-year warranty on the breaking of the frame
 - 6-month warranty on the other parts.
 Maestro / Coppa / Finta / Forza (domestic use only)
 - 2-year warranty on the breaking of the frame
 - 6-month warranty on the other parts.
 Scala series
 - 1-year warranty on the breaking of the frame (in professional use)
 - 5-year warranty on the breaking of the frame (in domestic use)
 - 6-month warranty on the other parts.

2. The warranty applies only to the material and construction defects with respect to this product or its components.
3. The warranty becomes defunct if:
 - This product is used incorrectly and/or carelessly and is used in such a way that it does not comply with its purpose.
 - This product is not assembled and maintained according to the instruction booklet.
 - Technical repairs to this product are not carried out professionally.
 - Parts, which are mounted afterwards, do not comply with the technical specifications of the product concerned or are mounted incorrectly.
 - Defects are a result of climatic influences such as corrosion, UV rays or normal disintegration.
 - The product is rented out or was made available to various unspecified persons in any other manner.
4. EXIT Toys will repair or replace according to its choice all material and construction defects that have been ascertained by EXIT Toys during the warranty period.
5. The owner of the EXIT Toys product is only entitled to the warranty by presenting the product for inspection at an EXIT Toys dealer. It should be handed to the EXIT Toys dealer, accompanied by the original purchase invoice.
6. In case of material and construction defects that have been ascertained by EXIT Toys, the product or its components will be repaired or replaced – according to its choice – free of charge during the warranty period mentioned in Article 1.
7. If the claim for warranty is not justifiable, all the costs are at the expense of the owner.
8. This warranty cannot be transferred to third parties.
9. The product is designed for personal use. It is not permitted to rent out or place the product in public areas like schools or day-care center. The guarantee and any other liabilities shall expire if the product is rented out or used in public areas. *does not apply for Scala series



Contact Information:

Dutch Toys Group B.V.
Edisonstraat 83 7006RB Doetinchem,
The Netherlands +31 314 323 005

info@exittoys.com

www.exittoys.com

EXIT Toys is port

Its I Till= ro mars !Tood

EXIT Toys is o registered trade muii ul Dutch Toys Group

Documents / Resources



[EXIT TOYS MSP-U009-V01 Scala Aluminum Soccer Goal](#) [pdf] User Manual
MSP-U009-V01 Scala Aluminum Soccer Goal, MSP-U009-V01, Scala Aluminum Soccer Goal, Aluminum Soccer Goal, Soccer Goal, Goal

References

- [plus.La](#)
- [EXITOYS Exitoys](#)
- [User Manual](#)

Manuals+, **Privacy Policy**

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.