

EXIT Pico Foldable Mini Goal Set User Manual

Home » EXIT » EXIT Pico Foldable Mini Goal Set User Manual



Pico Foldable Mini Goal Set 90x60x60cm (set of 2 goals) Warning! CHOKING HAZARD! – Small parts. Not for Children under 3 years old. Adult assembly required. This product should, at all times, be used by the child under direct supervision of an adult. OUTDOOR USE ONLY. Only for domestic use.

C € ⚠ WARNING:

CHOKING HAZARD - Small parts.

Not for children under 3 yrs.



Contents


- 1 Instructions
- 2 Introduction
- 3 Warnings for safe use:
- 4 Assembly and Installation Instructions
- **5 Care and Maintenance Instructions**
- **6 Guarantee Conditions & Service**
- 7 Documents / Resources
 - 7.1 References

X Instructions

1. Short bent tube 2 pieces



2. Long bent tube 2 pieces



3. Straight tube 2 pieces




4. Left Rotational component 1 piece



5. Logo 2 pieces





6. Net 1 piece



7. Right Rotational component 1 piece







Introduction

Congratulations on choosing the EXIT Pico soccer goals!

Have fun, be active and play outdoors.....

That's what keeps driving us to develop innovative, quality toys for cool kids.

We do everything possible to develop safe products for children. As our products are classed as toys, we comply with the toughest consumer safety regulations. Before launching our products onto the market, we have independent tests carried out for certification. We also continuously test our production runs and periodically have independent tests performed again as a further check. Only products which live up to the highest EXIT Toys standard are marked with and recognized by the EXIT-brand.

"We want to thank you for your custom and your confidence in this product. We're sure your kids will have as much fun as we did during development. Being openminded, we really appreciate all comments and ideas which will help us improve our products or develop new ones. You are invited to send your ideas to us at info@exittoys.com"

Please visit www.exittoys.com and discover more cool new products.

The EXIT Toys team

Warnings for safe use:

Adult supervision is required at all times when the goals are used by children.

- To reduce risk of entanglement, keep small children away from net area at all times.
- When properly assembled and used as intended, this goal is designed to provide any hours of playing enjoyment.
- Never let children climb on goal as this can result in goal falling over causing serious injury or death.
- The metal frame of the soccer goal will conduct electricity. Lights, extension cords, and all such electrical equipment must never be allowed to come in contact with the soccer goal.
- Inspect the soccer goal before each use. Make sure the strips and all parts are correctly and securely
 positioned and attached. Tighten any loose hardware.
 Replace any worn, defective, or missing parts.
- Wear comfortable clothing free of hooks, snaps, drawstrings or anything which may snag or catch in the soccer
 goal mesh. Remove jewelry, necklaces, and earrings.
- · Read all instructions and complete all assembly before using.

Assembly and Installation Instructions

- Adequate overhead clearance is essential. Provide clearance for wires, tree limbs, and other possible hazards.
- Lateral clearance is essential. Place the Soccer Goal away from walls, structures, fences, and other play areas. Maintain a clear space on all sides of the soccer goal. A minimum of 3m from frame edge is recommended.
- Never set-up the soccer goal in heavy rain, wind or storm conditions, especially storms.
- When moving the assembled soccer goal, have at least two people evenly the frame to lift the soccer goal off the ground.
- Place the soccer goal on a level surface before use.
- Secure the soccer goal against unauthorized and unsupervised use.

Care and Maintenance Instructions

Inspect the soccer goal before each use and replace any worn, defective, or missing parts. The following conditions could present potential hazards:

- 1. Missing, improperly positioned, or insecurely attached frame padding, barrier or enclosure
- 2. Punctures, frays, tears, or holes worn in the soccer goal mesh.
- 3. A bent or broken frame or support system.
- 4. Sharp protrusions on the frame or suspension.
- 5. Loosened or missing hardware, system.

Guarantee Conditions & Service

The owner of this product has the following guarantees on the product:

- 2 years from date of purchase on the frame (regular use).
- A 6-month guarantee is given on the other parts (regular use).
- The guarantee only applies for material/construction errors of the product and/or parts thereof.

The guarantee is not applicable and/or is invalidated in the following cases:

- The soccer goal has been handled without due care, has been involved in an accident, or has been fitted with non-approved parts.
- The product has not been assembled as per instructions or has not been correctly maintained.
- Parts fitted afterwards do not match the product's technical specifications or original parts have not been used or have not been fitted correctly.
- The soccer goal is used for professional purposes (hire, schools, etc.).
- Technical repairs to the product were not carried out professionally.
- Replacement of parts were not carried out on time.

The owner of the product can only claim a guarantee by presenting the original bill for the purchase to EXIT Toys or the dealer from whom the product was bought.

If the claim under the guarantee is refused, then all costs incurred must be paid by the owner. Guarantee is not transferable to third parties.



Contact:
Dutch Toys Group
P.O. Box 369, 7000 AJ Doetinchem
Edisonstraat 83, 7006RB Doetinchem

The Netherlands info@exittoys.com

www.exittoys.com

EXIT is a registered trade mark of Dutch Toys Group

Documents / Resources



EXIT Pico Foldable Mini Goal Set [pdf] User Manual

MST-41101-V03, Pico Foldable Mini Goal Set, Pico, Foldable Mini Goal Set, Mini Goal Set, Goal Set, Set

- O Toysrus.com, The Official Toys"R"Us Site Toys, Games, & More
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.