



EZCast TwinX C-1 Wireless Display Transmitter User Guide

[Home](#) » [EZCast](#) » EZCast TwinX C-1 Wireless Display Transmitter User Guide 



**EZCast TwinX C-1
Wireless Display Transmitter
Quick Start Guide
Rev 1.0**



Product information is subject to change without prior notice.

Contents

- [1 How to mirror](#)
- [2 How to pair EZCast TwinX with receiver](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

How to mirror


1. Simply plug into laptop or mobile

Plug EZCast TwinX C-1 to Type C port on laptop or mobile. Wait a few seconds until the flashing light on EZCast TwinX stops, and it will start mirroring automatically. Please make sure to install and pair to EZCast wireless display receiver if flashing over 20 seconds.



2. Stop and restart mirroring

Press the EZCast TwinX button to stop mirroring or restart mirroring.




Note: EZCast TwinX support mirroring for all laptops including Windows and MacOS, and Android mobiles supporting DP output.

How to pair EZCast TwinX with receiver

1. Turn on pairing mode for the receiver


Press the reset button (or insert the pin to press) for 2 seconds on the EZCast wireless display receiver. Release the button when the screen shows “Release the button to pair with EZCast”. Please make sure your receiver has been upgraded to the latest version.

Note: All EZCast wireless display receiver on our website supports EZCast TwinX pairing, except for Magic series products.



2. Press the EZCast TwinX button

Plug EZCast TwinX on a laptop or mobile to provide power. Press the EZCast TwinX button to complete pairing while the screen shows “Ready to pair”,



Note: There is 3 modes for the reset button on the receiver, depending on pressing duration.

1. Simple click: Switch the receiver to 2.4G/ 5G Hz Wi-Fi mode.
2. Press for 2 seconds: Turn on pairing mode for EZCast TwinX to pair.
3. Press for 10 seconds: Reset the receiver to default.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Caution: Any Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



Website: <https://www.EZCast.com>
YouTube: <https://www.YouTube.com/EZCast>

Documents / Resources

	<p>EZCast TwinX C-1 Wireless Display Transmitter [pdf] User Guide TwinX C-1, Wireless Display Transmitter</p>
---	---