



FALCON RIDGE PO-19RZR-RW01 2019 Polaris RZR Soft Rear Window Instruction Manual

[Home](#) » [FALCON RIDGE](#) » **FALCON RIDGE PO-19RZR-RW01 2019 Polaris RZR Soft Rear Window Instruction Manual** 



2515 Bypass Rd. Flemingsburg, KY 41041
606-845-7439

Instructions for Installation and Care of 2019 Polaris RZR Soft Rear Window
PO-19RZR-RW01

Contents

[1 PO-19RZR-RW01 2019 Polaris RZR Soft Rear Window](#)

[2 Documents / Resources](#)

[3 Related Posts](#)

PO-19RZR-RW01 2019 Polaris RZR Soft Rear Window

Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.

1. Be sure to read these instructions thoroughly before opening and installing the 2019 RZR Soft Rear Window.
2. Check over the parts included in the carton with the parts list shown below:



Velcro Hook strips:

“ “	12 each	3” long
“ “	2 each	5” long
“ “	1 each	24” long
“ “	2 each	26” long
Snap studs		6 each

- Installation of your Soft Rear Window is quite simple. Take the 5 adhesive velcro strips provided and attach them to the roll cage around the perimeter facing the rear of the vehicle. Take the Soft Rear Window and attach it to the vehicle.
- Lastly, install the snaps along the bottom of the window. It works best to pop the snaps into the sockets first. Then push the screw end into the plastic to make an indentation or mark. Then pull the snap out and screw it into the plastic.



Documents / Resources

<div>  <p>FALCON RIDGE</p> <p>PO-19RZR-RW01, 2019 Polaris RZR Soft Rear Window</p> <p>PO-19RZR-RW01, 2019 Polaris RZR Soft Rear Window, PO-19RZR-RW01 2019 Polaris RZR Soft Rear Window, Polaris RZR Soft Rear Window, RZR Soft Rear Window, Soft Rear Window</p>  </div>	<div> <p>FALCON RIDGE PO-19RZR-RW01 2019 Polaris RZR Soft Rear Window [pdf] Instruction Manual</p> <p>PO-19RZR-RW01, 2019 Polaris RZR Soft Rear Window, PO-19RZR-RW01 2019 Polaris RZR Soft Rear Window, Polaris RZR Soft Rear Window, RZR Soft Rear Window, Soft Rear Window</p> </div>
--	---