




FAME GIT0039302-000 Ocean Verb User Manual

[Home](#) » [Fame](#) » FAME GIT0039302-000 Ocean Verb User Manual 

Contents

- [1 FAME GIT0039302-000 Ocean Verb](#)
- [2 Product Information](#)
- [3 Specifications](#)
- [4 Product Usage Instructions](#)
- [5 Scope of Delivery](#)
- [6 Safety instructions](#)
- [7 Installation](#)
- [8 Specifications](#)
- [9 Troubleshooting](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)

FAME

FAME GIT0039302-000 Ocean Verb



Product Information

Product Name: Ocean Verb

Model Number: GIT0039302-000

Language: English, Deutsch

Manufacturer: Fame

Guarantee: The current general terms and conditions and guarantee conditions of Music Store Professional Safety Instructions! Please read before connection and operation! GmbH apply. Visit www.musicstore.de for more information.

Specifications

- Input Impedance: 500 k
- Output Impedance: 10 k
- Current Consumption: 7 mA
- Power Supply: DC 9V, center negative
- Dimensions (WxDxH): 36 x 75 x 26 mm
- Weight: 250 g

Product Usage Instructions

1. Read the safety instructions before connecting and operating the device.
2. Ensure that the device is operated indoors only.
3. Connect the device to musical instruments with electromagnetic pickups to change the sound of the signals.
4. Do not use the device improperly as it can cause personal injury or property damage.
5. The device should be operated by trained and competent users who are in full possession of their mental, physical, and sensory abilities.
6. If other persons want to use the device, they should be supervised or guided by a person responsible for their safety.
7. For any troubleshooting, refer to the manual.
8. To clean the device, follow the cleaning instructions in the manual.

9. Dispose of the device in accordance with environmental regulations.

Safety Instructions! Please read before connection and operation!

RISK OF ELECTRIC SHOCK. DO NOT OPEN

WARNING: To prevent the risk of electrocution, do not open the device. Please leave all maintenance and repairs to a qualified service workshop or contact your distributor.



The lightning flash symbol warns the user about non-insulated current and the risk of electrocution.



The exclamation mark symbol warns the user about important maintenance and operating instructions in the manual.



Intended for indoor use only.



Read the manual.

- Ensure that the supply voltage does not exceed the voltage capacity indicated on the housing of the device.
- In case of failure of the device, please contact the distributor and stop all operations of the device immediately.

Manufacturer: MUSIC STORE professional GmbH, Istanbulstraße 22-26, 51103 Cologne, Germany

- Please recycle the packaging correctly to protect the environment.
- Occasionally a new product may cause undesirable odours or even emit smoke for a short period of time. This reaction is normal and will disappear after a few minutes.
- To prevent condensation from forming in the device, please allow the device to adapt to the surrounding temperature before operating.
- Please position the device in a well ventilated area, beyond the reach of flammable materials or liquids.
- Do not block any ventilation openings, as it may cause over-heating.
- Please remove the power cable if the device is not operated for extended periods of time or maintenance is to be conducted.
- This device is designed to operate in environments with a maximum temperature of 40° Celsius.
- In case of a damaged power cable, it must be replaced by an original replacement part from the manufacturer.

Congratulations on your new Fame Ocean Verb!

Thank you for choosing a Fame product. Thanks to efficient development and economical production, Fame makes high-quality products at a fantastic price possible.

Please read these operating instructions carefully to be informed about all functions of this product and keep them for future reference

Have fun with your new product!

Your Fame Team



Guarante:

The current general terms and conditions and guarantee conditions of Music Store professional GmbH apply. Can be viewed under: www.musicstore.de If you have any questions or suggestions, please contact us:

Music Store professional GmbH Istanbulstr. 22-26

51103 Köln

Managing Director: Michael Sauer

WEEE-Reg.-No DE 41617453

Intended use

This device is designed to change the sound of the signals of musical instruments with electro-magnetic pickups. Improper use of the product is considered improper and can lead to personal injury or property damage. No liability is assumed for damage resulting from improper use. It must be ensured that the device is operated exclusively by trained and competent users who are in full possession of their mental, physical and sensory abilities. The use by other persons is only permitted under the supervision or guidance of a person responsible for their safety.

Scope of Delivery

Quantity	Contents
1x	Ocean Verb
1x	Manual

Safety instructions

DANGER! (For Babies and Children)

Wrapping, plastic foils and other packaging material must be properly stored or disposed of. It should be kept out of the reach of babies and children due to the risk of suffocation. Ensure that children never use the device unattended! Also make sure that children do not remove any (small) parts from the device, as they could suffocate if swallowed

DANGER! (electric shock due to high voltages in the device)

Do not remove the housing. There are no serviceable parts in the unit. Inside the device there are components which are under high electrical voltage. The device must not be used if damage or the absence of components, protective devices or housing parts is noticed!

DANGER! (electric shock caused by short circuit)

Modifications to the mains cable or the mains plug are prohibited. Failure to do so may result in fire or death hazard due to an electric shock

Warning! (Fire Hazard)

Make sure that the device is not exposed to any direct heat source and is used away from open fire. Never block or cover ventilation slots or the device itself.

Notice! (Operating Conditions)

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations

Warning! (Power Supply)

Make sure that the device voltage matches your local mains voltage. It is strongly recommended to protect your mains socket with a residual current circuit breaker (RCD). If you do not use your device for a longer period of time, disconnect the device from the mains to minimize dangers. The same applies to thunderstorms or floods, etc.


Installation

Always check the device for damage before use. Use the original packaging or suitable transport or storage packaging to protect the product optimally from influences such as dust or moisture, etc. when not in use

Operation

All connections of the device should be made before switching on. Use only high-quality cables that are as short as possible for the connections.

Connections and Control Elements




Number	Function	Description
1	MIX	Adjusts the proportion of the sound-altered signal.
2	DC 9V	Connection for an external power supply with 9 V DC voltage.
3	3-way toggle switch	Selects the different effect modes.
4	TONE	Tone control.
5	DECA Y	Controls the decay time of the effect.
6	Input	Input jack for a standard instrument cable (6.3mm mono jack).
7	LED	Lights up when effect pedal is in operation.
8	Output	With a standard instrument cable you can connect another effect pedal or your amplifier to this output .
9	TRUE BYPASS	Foot switch for activating or deactivating the pedal function.

Components and functions

Plug and connection assignment

Confi guration 6,35 mm mono jack:



Specifications

Model	Fame Ocean Verb
Input impedance	500 kW
Output impedance	10 kW
Current consumption	7 mA
Power supply	DC 9V power supply (-) inside
Dimensions	36 x 75 x 26 mm
Weight	250 g

Troubleshooting

The following overview is intended as an aid to rapid troubleshooting. If you are unsure, contact the manufacturer, the dealer or appropriate specialist personnel. Never open the device by yourself!

Symptoms	Troubleshooting
No Function	Check the correct power supply of the Ocean Verb.
No output	Check the cable connections from the instrument to the unit and on to the amplifier.

If the above troubleshooting has not been successful, please contact our service staff. You can find the contact details at www.musicstore.de

Cleaning

Regular cleaning of the device from dirt and dust increases the shelf life of the product. Always disconnect the unit from the power supply while cleaning it. Optical lenses should be cleaned with a dry microfiber cloth. This also optimises the light output. Never clean the device with water! Ventilation grilles and openings should always be free of dust and dirt. Compressed air sprays are ideal for this application.

Environmental Protection

Music Store professional GmbH always endeavours to reduce the burden of packaging to a minimum. The use of environmentally friendly and recyclable materials is always of fundamental importance. Please recycle the packaging after use.



Disposal of packaging Ensure that paper packaging, plastic material, etc. are recycled separately. Observe the labels and the corresponding regulations




Disposal of batteries: Batteries should not be thrown away! Please dispose of batteries in accordance with official regulations



Disposal of your old device

This device is subject to the WEEE directive (Waste Electrical and Electronic Equipment) in its currently valid form. The device must not be disposed of with normal household waste. The device is disposed of via an approved disposal company or your local waste disposal centre. The regulations valid in your country must be observed

Documents / Resources

	<p>FAME GIT0039302-000 Ocean Verb [pdf] User Manual GIT0039302-000 Ocean Verb, GIT0039302-000, Ocean Verb, Verb</p>
---	---

References

-  [Music Store Online-Shop für Musikinstrumente | MUSIC STORE professional](#)