



FANIMATION CRL4WH Remote Control User Guide

[Home](#) » [FANIMATION](#) » FANIMATION CRL4WH Remote Control User Guide 

FANIMATION CRL4WH Remote Control User Guide



DESCRIPTION: One Ceiling Fan & Light, 3 Speed Remote Control with Learn Receiver.

ELECTRICAL SPECS: 120 Volts, 60 Hertz, Fan 1.0 amp, Light Rating 190W (max.) Incandescent or Halogen, 5 Wire Installation.

FAN MODEL USED: May be used in conjunction with CWRL4 Wall Control See Catalog or visit our website www.fanimation.com for more information.

IMPORTANT: YOU MUST SET YOUR CEILING FAN TO HIGH SPEED AND LIGHT KIT (IF ANY) TO THE ON POSITION BEFORE OPERATING YOUR REMOTE CONTROL.

NOTE: If fan or supply wires are different colors than indicated, have this unit installed by a qualified electrician.

WARNING

To avoid possible electrical shock, be sure electricity is turned off at the main fuse box before wiring.

NOTE: If you are not sure if the outlet box is grounded, contact a licensed electrician for advise, as it must be grounded for safe operation.


Contents

- [1 INSTALLATION INSTRUCTIONS](#)
- [2 LEARN MODE PROCESS](#)
- [3 REMOTE FUNCTIONS](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)


INSTALLATION INSTRUCTIONS

1. Ceiling fan must be set at HIGH speed and light kit (If any) at the ON position by pressing the “Light Switch” after installation.
2. **Install Receiver in the Hanger Bracket:**

- Slide remote Receiver into the Hanger Bracket (**Figure 1**).



- Connect wires as indicated: (**Figure 2**)



- Green Hanger Bracket and Hanger Ball wires to BARE (ground) wire.
- BLACK Receiver Unit wire (AC IN L) to BLACK supply wire.

- WHITE Receiver Unit wire (AC IN N). to WHITE supply wire.
- WHITE Receiver Unit wire (TO MOTOR N) to WHITE fan wire.
- BLACK Receiver Unit wire (TO MOTOR L) to BLACK fan wire.
- BLUE Receiver Unit wire (FOR LIGHT DOWN) to BLUE light wire.
- Position all connected wires and receiver antenna to allow installation of ceiling canopy.
- Using canopy screws threaded into the hanger bracket reinstall ceiling canopy.
- Restore electrical power

LEARN MODE PROCESS

1. Control and receiver have been factory programmed. If replacing the transmitter or receiver, the learn mode process will need to be used.
2. After installing the unit and restoring power to your fan, open the battery cover (with battery, DC12V/A23 1pc, installed) and press and hold the "LEARNING BUTTON" 1~3seconds with a ball-point pen or similar object. FAN will turn off and then turn to medium speed, which indicates that the learning process has completed.
IMPORTANT: You must press the "LEARNING BUTTON" within 60 seconds of restoring power to the fan. Remote does not need to be re-learned when replacing the battery.
3. If light kit has CFL bulbs, please slide the "light dimmer function select switch" to on/off position. If installed incandescent light bulbs onto ceiling fan, please slide the "light dimmer function select switch" to dimmer position.
4. Please note, the remote can learn multiple receivers.
60 second time limit should eliminate need for this.

REMOTE FUNCTIONS

LIGHT: ON/OFF- Press and release immediately to turn on or off the light.

DIMMER: Press and hold to dim or brighten light to the desired level and release—feature can not be used with CFL bulbs

OFF: Turns off the fan

HIGH: Turns fan to high speed



MED: Turns fan to medium speed

LOW: Turns fan to low speed



WARNING

Check to see that all connections are tight, including ground, and that no bare wire is visible at the wire connectors, except for the ground wire. Do not operate fan until the blades is in place. Noise and fan damage could result.



10983 Bennett Parkway
 Zionsville, IN 46077
 (888) 567-2055 • FAX (866) 482-5215
 Outside U.S. call (317) 733-4113
 Visit Our Website www.fanimation.com

Copyright 2010 Fanimation 2010/02



Documents / Resources



[FANIMATION CRL4WH Remote Control](#) [pdf] User Guide
 CRL4WH Remote Control, CRL4WH, Remote Control, Control

References

-  [Fanimation](#)
-  [Manual-Hub.com - Free PDF manuals!](#)
- [User Manual](#)

Manuals+. [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.