Manuals+ — User Manuals Simplified.

Fanvil CS30 USB Bluetooth Speakerphone User Manual

Contents

Fanvil CS30 USB Bluetooth Speakerphone

Product introduction

USB/Bluetooth Speakerphone is an omni-directional microphone and a bluetooth speaker.
It is used as a high-quality microphone and speaker for online meeting and compatible with apps such as Zoom\Teams. Users can enjoy clear remote conference experience anytime, anywhere.

## Accessories List

Speakerphone

Instructions

Data cable

Buttons and lighting instructions

Phone Calls

Short press to answer/ hang up calls

Volume/power indicator

● means on   ○ means off

Volume indicator

● ● ● ● ● Maximum volume

○ ○ ○ ○ ○ Minimum volume

Power indicator (short press on power button)

● ● ● ● ● Power>80%

● ○ ○ ○ ○ Power≤20%

— Volume down

Short press to turn down the volume

+ Volume up

Short press to turn up the volume

Microphone

Short press to switch microphone status

Status Indicator
Red: Microphone mute
White: Microphone unmute

Buttons and lighting instructions

Power

Press and hold for 3 seconds to turn on or off the device

Status Indicator
Red light breathing: battery is below 10%
White light breathing: charging
White light on: battery full or not charging

*When the power is off and charging, the light goes off to indicate that it is full

Bluetooth

Press and hold for 2 seconds to pair
Short press to disconnect Bluetooth

Status Indicator
Blue flashing: Bluetooth pairing
Blue on: Bluetooth connected

Instructions for use

Device connection

Method 1: USB connection

- Connect the device to the computer via the supplied USB cable, and when you hear a hint tone, the connection is successful.
- Choose "Fanvil CS30" as the input/output audio device in system setting or in the online meeting software.

Method 2: Bluetooth connection

- Press the Bluetooth key for 2 seconds until the Bluetooth indicator flashes. Then open the phone or PC Bluetooth setting page, search the Bluetooth device "Fanvil CS30" for pairing; Click to connect.
  If you have an Android phone that supports NFC, turn on the NFC of the phone and touch the device's NFC area to connect to Bluetooth.

Tip: The current version does not support OTG data cable directly connected to the phone

Charging instructions

Charging

- When using the USB cable to connect to the computer, the device will enter the charging mode.
- If you use a power adapter to supply power, you should purchase a power adapter that is FCC/CE certified and meets the requirements of the standard.

Tip: Before using the device for the first time, it is recommended that charge at least 1 hour to ensure sufficient power

Product name	AI Meeting Box
Product model	CS30
Product dimensions	112.5mm x 112.5mm x 35.4mm
Bluetooth	Bluetooth V5.1
Pickup radius	4 meters/13 ft
Microphone	4 omnidirectional microphone
Loudspeaker	5W
Battery capacity	2000mAh
Charging	5V—2A Type-C port

Frequently Asked Questions

Questions	Suggestions
The volume is not synchronized when the device is connected to the phone by Bluetooth	1. Confirm whether the phone supports Bluetooth sound synchronization, some Android phones do not support volume synchronization. 2. Some phone needs to open the volume setting permission in the system settings.
When the device is connected to the phone by Bluetooth, the ringtone of phone calls does not come out from the device	1.Check whether the phone volume is turned on, or the volume is too low. 2.Check whether the device can speak normally. 3.Choose audio input/output in the meeting software.
No sound when device is connected to	1.It is recommended that when playing music, select the speaker with the name "stereo" on your PC.

Windows PC by Bluetooth	2.It is recommended to choose the speaker with the name "hand free" for the audio output speaker during
	the call or meeting.

	1.Check whether the input /output of the	call
No sound when the device is connected to	software are properly set to "Fanvil CS30".	
FaceTime/ Zoom/Teams/Google	2.Check whether the computer audio	driver
Hangouts etc. by Bluetooth	is normal, it is recommended to	restart
	the computer and try again.	

No response when the device is connected to the computer using USB	1.Check whether the device is connected to phone, please disconnect the connection first, and then use the cable to connect the device. 2.Check whether the USB data cable is damaged. 3.Reboot the device and try again.

Fanvil Technology Co., Ltd

Website: www.fanvil.com
EMail: sales@fanvil.com support@fanvil.com
Tel: +86-755-2640-2199 Fax: +86-755-2640-2618
Add: 10/F Block A, Dualshine Global Science Innovation
Center, Honglang North 2nd Road, Bao'an District, Shenzhen,China

Documents / Resources

Fanvil USB/Bluetooth Speakerphone User Manual www.fanvil.com	**Fanvil CS30 USB Bluetooth Speakerphone** [pdf] User Manual CS30, USB Bluetooth Speakerphone, CS30 USB Bluetooth Speakerphone, Bluetooth Speaker phone, Speakerphone

References

- **F Fanvil Technology Co., Ltd**