

FAQs 4G Camera how to Connect WIFI? User Manual

Home » FAQs » FAQs 4G Camera how to Connect WIFI? User Manual




Contents

- 1 FAQs 4G Camera how to Connect WIFI?
- 2 Documents / Resources
- **3 Related Posts**

FAQs 4G Camera how to Connect WIFI?






Q: 4G camera how to connect WIFI?


R: First, you can not configure the 4G camera's WIFI via the phone APP - "WIFI settings".



Need to configure the WIFI through the 4G MIFI page as shown below, if you do not know enter this page, please read the document "1- You need to know something first in the 4G camera!"



Enter "WI-FI Settings" page



Then enter "Internet Wi-Fi "page, Click the "Add" button to add WIFI.



Select the WIFI and enter the WIFI password, then click "Apply".


Select the WIFI and enter the WIFI password, then click "Apply". Wi-Fi Switch Enable O Disable SSID WPS Add Wi-Fi Hotspot Network Name(SSID) * SNOCAM Security Mode WPA-PSK/WPA2-PSK Advanced Settings WPA Algorithms ○ TKIP ○ AES ® AUTO WLAN MAC Filter Pass Phrase * ****** Display Password SSID Signal Security Mode • WPA-PSK/WPA2-PSK SNOCAM 7 ChinaNet-uR56 WPA-PSK/WPA2-PSK

WPA-PSK/WPA2-PSK

Show "WIFI is connected" and the above icon indicates the connection WIFI mode.


LHYK

0



Note:

When the WIFI is connected, 4G camera connect Internet via WIFI, if you want the 4G camera connect the Internet via the 4G SIM card, please select "WWAN"



Documents / Resources



Manuals+,