

FAQs High Speed Internet Change Your Wi-Fi Settings User Manual

Home » FAQs » FAQs High Speed Internet Change Your Wi-Fi Settings User Manual




Contents

- 1 FAQs High Speed Internet Change Your Wi-Fi
- 2 High-Speed Internet Change your Wi-Fi settings
- 3 Documents / Resources
 - 3.1 References
- **4 Related Posts**



FAQs High Speed Internet Change Your Wi-Fi Settings



High-Speed Internet Change your Wi-Fi settings


To change the wireless settings in your your modem/gateway, we recommend connecting a laptop or PC directly to the modem with an Ethernet cable into one of the four yellow jacks on the back of the modem/gateway. Once connected, open your web browser and visit the following address: http://192.168.1.254 To log in you will need the security code, or security access code, which is written on the back of the modem. Please note that this is different than the wifi password which is also written on the back of the modem. Once logged in you can click on the wifi/wireless menu to access wireless settings,including:

Enable or disable wifi

- · Change the wireless network name or password
- · Change the wireless channel or frequency
- Other miscellaneous wifi settings

Unique solution ID: #1105 Author: IgLou Customer Support Last update: 2020-03-26 15:38 (c) 2022 IgLou Customer Service <<u>support@iglou.com></u>

Documents / Resources



References

• TCPDF

• © IgLou Support Website - Change your Wi-Fi settings

Manuals+,