

## FAQs How do I turn up GPS instruction volume (I Can't hear it over music) User Manual


[Home](#) » [FAQs](#) » FAQs How do I turn up GPS instruction volume (I Can't hear it over music) User Manual 

### Contents

- [1 FAQs How do I turn up GPS instruction volume \(I Can't hear it over music\)](#)
- [2 Trouble Shooting](#)
- [3 Wiring – Back Panel](#)
- [4 Wiring – Color Wiring](#)
- [5 DVD](#)
- [6 Bluetooth](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)



### FAQs How do I turn up GPS instruction volume (I Can't hear it over music)




## Trouble Shooting

- Q: How do I turn up GPS instruction volume (I Can't hear it over music)  
A: Change GPS sound settings Go to Navi >Settings> Sounds> Set GPS voice level to max> Set radio volume to min (Adjust accordingly)
- Q: How do I update my map card.  
A: The radio will notify you when a map update becomes available. We will need to send out a new map card from our parts department. Log onto [www.PyleUSA.com](http://www.PyleUSA.com) and open a parts ticket under "contact us" requesting the map update.
- Q: Where can I download firmware updates?  
A: This unit's hardware does not allow it to be updated with new OS or firmware.
- Q: How do I access the Internet?  
A: This device is not capable of receiving internet data.
- Q: How do I use/ set-up RDS?  
A: (\*Traffic and weather feature only available in Europe)
- Q: My Bluetooth microphone is not working as expected A: -Check that nothing is covering microphone port.
  - Check to see if closer proximity to the mic affects its pickup
  - Check that phone connection is good
  - Make sure the call recipient has speaker volume set to an appropriate level
  - Check that the mic is not picking up too much background noise
  - **Note:** The built-in mic cannot be changed, replaced or upgraded.
- Q: I am having trouble setting up Bluetooth  
A: Check that your device is Bluetooth compatible 4.0+
  - Check if you are able to pair with alternate devices via Bluetooth
  - Clear out your device history in your Bluetooth setting menu and attempt to pair/ connect again
- Q: My Map card no longer loads (COCKPIT ERROR DISPLAYED)  
A: This is caused by bug in map software. Please contact Tech Support: Pyle, [www.PyleUSA.com](http://www.PyleUSA.com) go to the "contact us" page. A: You may be able to fix the software on your own
  - Insert GPS card into computer
  - Open text file under Primo\save\profiles\01 \system.ini
  - Edit the file to return the cockpit type to "1" Deleting the profile folder will default the unit's settings back to cockpit number 1
- Q: How do I play video files? My unit cannot read my digital video files.  
A: Make sure SD card is compatible  
A: Check file format of your file (You may need to convert your video file to an alternate file format)
- Q: My unit shows 5 circles and will not load  
A: Your unit requires touchscreen calibration.


You have entered the 'Touch Screen Calibration Menu'. For optimum touchscreen performance, this feature enables you to enjoy the best functionality of your device's touch screen. To complete the touchscreen calibration, an "X" will appear in the circles on the screen in numbered order, continue to press the center of the "X" as it passes through each numbered circle.

(In circle number one, you will see an "X": touch the center of the "X": then the "X" will move to circle number two. Continue to touch the center of the 'X' as it will move to the other circles in numbered order. If calibration senses an error, the process may restart; Repeat if necessary.)

## Wiring – Back Panel



## Wiring – Color Wiring



Wiring					
		Radio Antenna		Radio antenna receptacle	
		Subwoofer Output		Pre amp subwoofer output (SV)	
		Audio / Video Input		Auxiliary input for external hardware	
		Audio / Video Output 1		Connect to headrest display (Optional)	
		Audio/ Video Output 2		Connect to headrest display (Optional)	
	<b>Green/White</b>	SW KEY	Steering wheel control Key 1 interface wire		
	<b>Blue/White</b>	AMP REMOTE TURN ON	DC 12 + Volt Remote turn on trigger for external amplifier		
	<b>Orange</b>	ILLUMINATION	12 volt+ trigger dash board illumination		
	<b>Brown</b>	ACK UP CAMERA 1	12 volt+ trigger from reverse lights		
	<b>Pink</b>	PARKING	Connect to parking brake ground. Disables video play unless grounded		
	<b>Blue</b>	AUTO ANTENNA	12 volt+ trigger output		
	<b>Gray/White</b>	ROUND	Steering wheel control Key 2 interface wire		
	<b>Black (RCA)</b>	CAM VIDEO IN		Camera RCA video input for use with rearview camera	
	<b>Red</b>	Ace		Ignition Accessory 12V+	
	<b>Yellow</b>	FUSE/ POWER B+	Connect to (+) side of car battery		
	<b>Black</b>	GROUND	Connect to (-) side of car battery		
	<b>Black (RCA)</b>	Subwoofer	Subwoofer Output		
	<b>Purple</b>	Speaker Rear R	Rear right speaker	Purple (+)	Purple/Black(-)
	<b>Green</b>	Speaker Rear L	Rear left speaker	Green (+)	Green/Black (-)
	Gray	Speaker Front R	Front right speaker	Gray (+)	Gray/Black (-)

## DVD



















DVD app will only open if a compatible DVD disc is detected.


### Scrubbing

Press and drag along the time line to quickly skip through DVD times line.

(**Note:** DVD formatting does not allow scrubbing through previews and warnings)

### Menu options & controls:

	Stop the DVD		EQ
	Play previous channel		Repeat all
	Pause		AB repeat
	Play next channel		Audio
	Fast Backward		Turn subtitles on/off
	Fast Forward		Angle
	Zoom in on		Title
	Dialing		Menu
	Volume		Page



## Bluetooth

Bluetooth app allows Bluetooth pairing with compatible devices for making calls and music playback. To pair your phone, ensure Bluetooth is enabled in your phone's system settings and that you are disconnected from all other devices. In the Bluetooth app of your radio, press the "Gear" icon in the left column to access Bluetooth settings. Next, press the "Magnifying glass" icon to set the radio into pair mode. The radio will then display "searching" and show all nearby compatible Bluetooth devices:

- Select your phone from the list, and tap a second time to initiate pairing.
- Your phone should now display a pin pad where you will enter "0000"
- Check that device named "CAR\_KITT" shows as connected on your phone.

**Note:** Once your phone is paired, you can use the other functions within the radio's Bluetooth app. Left hand column:

- Select the "Keypad" icon to dial out using the radio's number pad
- Select the "address book" icon to display your phone's contact list. You will need to import your contact list using the "download" icon located in the right column of the Bluetooth app.
- Select the "phone" icon to see a log of incoming and outgoing calls
- Select the "gear" icon for phone pairing and selection options
- Select the "headphones" icon for music playback controls


### Right hand column:

- "Trash" delete currently selected entry

- “Download” Use to download contact data to address book
- “Speaker selection” Switch between car speaker /mic and phone speaker /mic



**Documents / Resources**

	<p><a href="#">FAQs How do I turn up GPS instruction volume (I Can't hear it over music)</a> [pdf] User Manual</p> <p>PLT85BTCM, 2A4GI-PLT85BTCM, 2A4GIPLT85BTCM, How do I turn up GPS instruction volume I Can t hear it over music, How do I turn up GPS instruction volume I Can t hear it over music</p>
---	--