



FAQs How to connect the headphone User Manual

[Home](#) » [FAQs](#) » FAQs How to connect the headphone User Manual 

- Contents
- 1 [FAQs How to connect the headphone](#)
 - 2 [Documents / Resources](#)
 - 3 [Related Posts](#)

FAQs How to connect the headphone



How to connect the headphone ?

A: Press and hold the Multi functional button to switch ON the headphone and it would enter BT mode by default. Scan for “ZEB-BANG” on your phone and connect it. (Password – 0000, if prompted)

What are the different LED indications?

A: Red LED glows – Charging.

Red LED turns OFF – Full charge.

Red and Blue LED blinks alternatively – BT Discover Mode.

Blue LED flashes once in 5 seconds – Headphone is connected to a device

What are the different modes in the headphone ?

A: Wireless BT & AUX.

How to trigger Voice Assistant using the headphone?

A: Long press the Multi functional button to trigger the voice assistant in your smartphone.

How to control media using the headphone?

A: Short press the +/- button to increase/decrease the volume respectively.

Long press the +/- button to change to next/previous songs respectively.

Single press the Multi functional button to Play/Pause a song.

What is the operating range of the headphone in wireless mode?

A: 8-10 meters.

Does the headphone have call function?


A: Yes.

Single press the Multi functional button to answer/hang up a call. Long press the Multi functional button to reject an incoming call.

What is the charging voltage?

A: DC 5V with micro USB cable.

Documents / Resources

	FAQs How to connect the headphone [pdf] User Manual How to connect the headphone
---	---