




FAQs Which cable goes with which Switch Wired controller? User Manual

[Home](#) » [FAQs](#) » FAQs Which cable goes with which Switch Wired controller? User Manual 



Which cable goes with which Switch Wired controller?

Along with the rest of the electronics industry, PowerA is transitioning to updated USB technologies where possible.

The follow is a list of wired Nintendo Switch controllers and their associated cable (as of Jan 2021):

USB Type-C:

- NSW Nano Wireless Controllers
- NSW Fusion Wireless/Wired Controllers
- NSW Enhanced Wireless 900mAh Rechargeable Controllers

USB Micro-B:

- NSW Wired controllers
- NSW Enhanced Wireless AA battery Controllers
- NSW GameCube Wired

Does the Nintendo Switch Wired Controller work with PC?

The Switch Wired Controllers are designed specifically to work with the Nintendo Switch console. While the controller may connect to the PC, there may be compatibility issues that occur preventing the user from receiving the full functionality of the controller. As such, we do not recommend that this controller be used for anything outside of the Switch Console. [Nintendo Switch Wired Controller Guide and Features](#)



Contents

- [1 Features:](#)
- [2 Basic Usage:](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

Features:

1. 8ft Removable USB Cable

Basic Usage:

1. Connect multiple wired controllers to the Nintendo Switch Console at a time. On-screen notifications will indicate which USB channel each controller is connected to.

Why don't I feel any vibration when using this controller?

This product does not support vibration functionality.


Why isn't my controller connecting to my Nintendo Switch Console?

1. Confirm that the USB Cable is securely connected to the Wired Controller and the Nintendo Switch Dock.
2. Confirm that the Nintendo Switch is powered on and connected to an external display before connecting your wired controller.
3. Confirm that your Nintendo Switch has the latest System Update installed.

How do I set up my Nintendo Switch Wired Controller?

1. Make sure your Nintendo Switch System is powered on and connected to your TV.
2. Insert the USB cable into a USB port on the Nintendo Switch Dock. Connect the other end of the cable to the wired controller. Your wired controller is now ready for use.

Documents / Resources

	<p>FAQs Which cable goes with which Switch Wired controller? [pdf] User Manual</p> <p>Which cable goes with which Switch Wired controller, Why isn t my controller connecting to my Nintendo Switch Console</p>
---	--