



FastForward 3 Mode Vertical Mouse




Contents [[hide](#)]

- [1 Package Contents](#)
- [2 Button Overview](#)
- [3 Customer Support](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)


Package Contents



- User manual



- Charging cable USB-C to USB-C



- USB-C Dongle



Congratulations on your new mouse, FastForward!

With FastForward, you work ergonomically, efficiently and silently.


Enjoy super fast scrolling, one button for all your open windows and a high DPI. Work wired or switch effortlessly between as many as three devices. Plus, you will benefit from an extra-long guarantee after registering this product (see packaging)!

Button Overview

Turn on and choose Win (for Windows) or Mac (for Apple products).

Plug in cable for wired use.

For wireless use, continue reading below.



(Pairing name: FastForward Mouse)

Press button to toggle between type C receiver and bluetooth mode 1 or bluetooth mode 2. Multiple devices can be stored this way.

To connect a new device, select the connection mode and long press (3 seconds). The LED will start blinking.

A. Left key

B. Right key

C. Smart flying scroll wheel

Give the mouse wheel a quick flick to let it fly to the top or bottom of the page for increased productivity.

D. DPI button (see G)


E. Win: Forward button

Mac: Switch Application → *

F. Win: Backward button

Mac: Switch Application ← *

G. Status and charging light



DPI (blue light)

1000 – 1 x 🌟

1600 – 2x 🌟

2400 – 3x 🌟

3200 – 4x 🌟

5000 – 5x 🌟

Battery (red light)

Low – blinking light

Charging – solid light

Full – light turns off


Warning: Only use PC port or 5.0V charger. Do not use fast charger.

H. Productivity button

Win: Open task window or

Mac: Mission control

- I. Channel light
- J. Mode switch key
- K. Windows/Power Off/Mac
- L. Type C charge port



Tip: Use 'sensible side buttons' app to change function on Mac.



At end of life, the resources used in this device can be recycled if it is disposed with electronic waste.

Customer Support

Product information



Made in China



Documents / Resources

	FastForward 3 Mode Vertical Mouse [pdf] User Manual 3 Mode Vertical Mouse, Vertical Mouse, Mouse
--	---

References

- [User Manual](#)

3 Mode Vertical Mouse, FastForward, mouse, Vertical

FastForward Mouse

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.