

Contents [[hide](#)]

- [1 FASTMIND LABS PULSE Series One App](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 GET STARTED](#)
- [5 FAQs](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)

FASTMIND LABS

FASTMIND LABS PULSE Series One App



Specifications

- FCC ID: 2BQSO-WS01X
- Model: PULSE
- RF Exposure: Compliant with general RF exposure requirements
- Usage: Portable exposure condition without restriction

Product Usage Instructions

1. Ensure the device is fully charged before initial use.
2. Power on the device by pressing and holding the designated power button.
3. Follow the on-screen prompts for initial setup and configuration.
4. To start using the device, navigate through the menu options using the provided controls.
5. Refer to the user manual for specific functionalities and features of the device.
6. Properly maintain and clean the device as per the care guidelines provided.
7. If you encounter any issues, refer to the troubleshooting section of the user manual or visit the support website for assistance.

GET STARTED

Follow these steps to unlock your body's pattern with PULSE.

1. Download Pulse App. Available for iPhone and Android.



2. Charge Your Pulse. Use the included charger and USB-C cable.



3. Connect in App. Follow pairing instructions in the app.



4. Wear Pulse stays on at all times.



5. Limited data shown initially. Full insights are available after calibration.





Front

PULSE

- THE HYPERWEAVE

Back

QUICK CARE GUIDE

SPOT CLEAN

For light dirt, wipe with a damp cloth,

GENTLE WASH

For a deeper clean, hand wash with cool water and a drop of mild soap. Rinse thoroughly.

AIR DRY ONLY

Pat with a towel and lay flat to air dry completely before wearing.

- Avoid direct heat or sunlight, as it can cause fading and damage.
- For more detailed information, please visit pulse.site/support

For more detailed information, please visit pulse.site/support

Front

PULSE

- THE FOUNDER

Back

WIPE CLEAN

Regularly wipe the strap with a soft, dry, lint-free cloth., For tougher grime, you can use a soft-bristle brush to gently clean the mesh.

DRY IMMEDIATELY

- If the strap gets wet, dry it thoroughly with a soft cloth.
- Prolonged exposure to water can cause fading and damage.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and uses can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:

The device has been evaluated to meet the general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

FAQs

Q: Is the PULSE device waterproof?

A: No, the PULSE device is not waterproof. Avoid exposing it to water or moisture to prevent damage.

Q: How do I charge the device?

A: Use the provided charging cable to connect the device to a power source. Follow the charging guidelines mentioned in the user manual.

Q: Can the device be used while charging?

A: Yes, you can use the device while it is charging. However, ensure that the charging cable does not interfere with the device's operation.

Q: What should I do if the device freezes?

A: In case of a device freeze, try restarting it by performing a soft reset. If the issue persists, contact customer support for further assistance.

Documents / Resources



[FASTMIND LABS PULSE Series One App \[pdf\]](#) User Guide

WS01X, 2BQSO-WS01X, 2BQSOWS01X, PULSE Series One App, Series One App, One App, App

References

- [User Manual](#)

FASTMIND LABS

2BQSO-WS01X, 2BQSOWS01X, app, FASTMIND LABS, One App, PULSE Series One App, Series One App, WS01X

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.