



Feasycom Co FSC-BP119D Bluetooth Audio Transmitter Instruction Manual

[Home](#) » [Feasycom Co](#) » Feasycom Co FSC-BP119D Bluetooth Audio Transmitter Instruction Manual 




FSC-BP119D Bluetooth Audio Transmitter Product Manual

Contents

- [1 Product Introduction](#)
- [2 Transmitter operation steps](#)
- [3 Main parameters of the product](#)
- [4 Packaging List](#)
- [5 Fault handling](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

Product Introduction


This product is a USB low-power Bluetooth Audio (LE Audio) transmitter, which is easy to operate, plug and play, and can freely send all audio signals. Products that can be plugged into Windows system, including laptops and desktop computers, personal digital assistant, televisions, etc., can be connected to multiple lowpower Bluetooth speakers or Bluetooth headsets within the signal range without restrictions.



Connection diagram (capable of connecting one or more headphones and speakers)

Transmitter operation steps

This product is connected to a Bluetooth device (Bluetooth headset) and can play wireless music.

1. Insert FSC-BP119D into a laptop, desktop computer, or TV with Windows system, and the blue light will start flashing
2. Click on the volume icon  in the bottom right corner and select the headphone FSC-BP119D USB Audio



3. When playing music, it is recommended to set the initial volume to 10, and gradually increase or decrease the volume as needed later
4. Turn on the accompanying LE Audio speaker, the blue light flashes, remains on after successful connection, and you can hear music

Main parameters of the product

Bluetooth version: V5.3

Functional features: Low power Bluetooth audio (LE Audio) transmission

Port type: Standard USB

One connects with multiple: can connect multiple Bluetooth speakers or Bluetooth headphones (LE Audio receiver)

Transmission distance: up to 100M (open environment)

Working voltage: USB 5V

Power consumption: <40mA;

Packaging List

Bluetooth transmitter x1


Product manual x1

Fault handling

When encountering problems, please contact Feasycom aftersales service and do not disassemble or repair them yourself in order to protect your rights.

Tel: 86-755-27924639, 86-755-23062695

Shenzhen Feasycom Co.,LTD

	<p>Feasycom Co FSC-BP119D Bluetooth Audio Transmitter [pdf] Instruction Manual</p> <p>FSC-BP119D Bluetooth Audio Transmitter, FSC-BP119D, Bluetooth Audio Transmitter, Audio Transmitter, Transmitter</p>
---	---