

FEITIAN SlimTag Security Key



FEITIAN SlimTag Security Key User Guide

[Home](#) » [Feitian](#) » FEITIAN SlimTag Security Key User Guide 

Contents

- [1 FEI TIAN SlimTag Security Key](#)
- [2 Getting Started](#)
- [3 Add Your SlimTag](#)
- [4 Locate Your SlimTag](#)
- [5 Notifications](#)
- [6 When Your SlimTag Is Lost](#)
- [7 Resetting SlimTag](#)
- [8 Extras](#)
- [9 The Fine Print](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)

FEITIAN

FEI TIAN SlimTag Security Key



Getting Started

Power On / Off

Press the SlimTag Function Button once to turn it on. It should beep once to indicate that it is powered on. To

power off, hold the same button for at least three seconds. You will hear two beeps to indicate that your SlimTag is powered off.

Check For Updates

To use the Apple® Find My™ app to locate this item, the latest version of iOS®, iPadOS®, or macOS® is recommended. The Find Items app on Apple Watch® requires the latest version of watchOS®.

Add Your SlimTag

Start The app

Open Find My app on your supported iPhone®.

Connect Your SlimTag

- Press the function button once to power on your SlimTag.
- Tap+, then “Add another item”.
- Once your SlimTag is located, tap “Connect”
- Enter a name choose an emoji for your SlimTag and tap “Continue”.
- Find My will ask for confirmation to add your SlimTag to your Apple ID Tap “Agree”
- Tap “Finish” and your SlimTag will be set up and ready to be used.

Locate Your SlimTag

Find SlimTag When It’s Nearby:

- Open the Find My app and select the “Items” tab or open the Find Items app on your Apple Watch.
- Tap on your SlimTag from the list.
- Tap “Play Sound” to make your SlimTag beep.
- Tap “Stop Sound” to stop the beeps once you find them.

Connect Your SlimTag

- Open the Find My app and select the “Items” tab or open the Find Items app on your Apple Watch.
- Tap on your SlimTag from the list.
- Your SlimTag’s location will appear on the Map with a timestamp of when the item was located.
- To navigate to the SlimTag’s location, tap “Directions” to open Apple Maps.

Notifications

Enabling “Notify When Left Behind”:

Open the Find My app and select the “Items” tab or open the Find Items app on your Apple Watch. Tap on your SlimTag from the list. Under “Notifications” enable the “Notify When Left Behind” toggle. You will receive a notification when you leave your SlimTag behind and it’s no longer in range of your device.

Enabling “Notify When Found”

Under “Notifications”, enable the “Notify When Found” toggle. When your SlimTag is seen by another Find My network device, you will receive a notification of its location.

Note: “Notify When Found” can only be activated when your SlimTag is out of range.

When Your SlimTag Is Lost

Enabling “Lost Mode”:

Open the Find My app and select the “Items” tab or open the Find Items app on your Apple Watch. Tap on your SlimTag from the list. Under “Lost Mode” tap “Enable”. A screen detailing Lost Mode will pop up, tap “Continue”. Enter your phone number or email address, and tap “Next”. You may enter a message that will be shared with the person that finds your item. Tap “Activate” to enable “Lost Mode”.

- **Note:** When “Lost Mode” is enabled, “Notify When Found” is automatically enabled.
- **Note:** When “Lost Mode” is enabled, your SlimTag is locked and cannot be paired to a new device.

Resetting SlimTag

Remove The SlimTag From the Find My app

- Open the Find My app and select the “Items” tab.
- Tap on your SlimTag from the list.
- Please ensure “Lost Mode” is disabled.
- Scroll to the bottom of the screen and tap “Remove item”.
- A summary will open, tap “Remove” to confirm.

Factory Reset Your SlimTag

- After successfully removing the SlimTag from the Find My app, press the SlimTag’s function button four times rapidly and then hold it a fifth time until you hear a ringing chime.
- The SlimTag is now reset and ready to be paired with a new Apple ID.

Extras

Unwanted tracking

If any Find My Network accessory separated from its owner is seen moving with you over time, you’ll be notified in one of two ways:

1. If you have an iPhone, iPad®, or iPod touch®, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later.
2. If you don’t have an iOS device or a smartphone, a Find My network accessory that hasn’t been with its owner for some time will emit a sound when it’s moved. These features were created specifically to discourage people from trying to track you without your knowledge.

The Fine Print

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.


NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used per the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and the receiver. Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, or Mac®. Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple or the maker of your item, can view its location. Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My Network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Documents / Resources

	FEITIAN SlimTag Security Key [pdf] User Guide SlimTag Security Key, SlimTag, Security Key, Key
---	---

References

- [User Manual](#)

