




## FeiyuTech Remote Handle for Feiyu Pocket 3 Instructions

[Home](#) » [FeiyuTech](#) » FeiyuTech Remote Handle for Feiyu Pocket 3 Instructions 

### FeiyuTech Remote Handle for Feiyu Pocket 3



## Contents

- 1 Suggestion
- 2 Tutorial
- 3 Download APP
- 4 Overview
- 5 List
- 6 Start to Use
  - 6.1 Charging
  - 6.2 Connection
- 7 Operation
  - 7.1 Power button
  - 7.2 Joystick
  - 7.3 Gimbal mode button
  - 7.4 Shutter button
  - 7.5 Zoom button
  - 7.6 Screen Operation
  - 7.7 Indicator light instructions
- 8 Specifications
- 9 Find More Features
- 10 CUSTOMER SUPPORT
- 11 Documents / Resources
  - 11.1 References
- 12 Related Posts

## Suggestion

This product includes below information, please read the information before using it.

1. Quick start guide
2. Online instruction
3. Tutorial

## Tutorial

\* The tutorial videos can be watched at FeiyuTech official website or scan the QR code.

<https://www.feiyu-tech.com/play/>



## Download APP

Connect with FeiyuCam App to achieve more functions.

Scan the QR code to download the app, or search for “FeiyuCam” in the App Store or Google Play.

\* Requires iOS 13.0 or above, Android 6.0 or above.

## iOS




## Android



\* This product dose NOT include Feiyu Pocket 3

## Overview



1. Touch screen
2. USB-C charging port
3. Joystick
4. Shutter button
5. Zoom button
6. Microphone
7. 1/4 inch thread Hole
8. USB-C port cover
9. Power button
10. Gimbal mode button
11. Wrist strap Hole
12. Gimbal connecting plug

## List



①



②



③



④



⑤

① Remote Handle x 1

- ② USB-C Cable x 1
- ③ Portable bag x 1
- ④ Wrist strap x 1
- ⑤ Manual x 1

Start to Use






- 1. Please fully charge the battery before powering on the product for the first time.
- 2. When not in use, power off the product

Charging

Connect USB-C cable with charging port to charge.

We recommend that you charge your camera at least once a month.

Charging status	While working (screen status)	While off (indicator status)
Charging	 Display	Red light is on
Complete	 Disappear	Green light is on




Connection

USB-C connection

Put the dovetail slot which at the button of Feiyu Pocket 3 stabilized camera aim to the convex slot of remote handle, and slide in along the slot to connect the USB-C port.


Then users can control the camera through the remote handle after power on.



### Wireless connection

Before using for the first time, please connect the remote handle with camera physically (Refer to 3.2.1), and power on.

Then detach the remote handle and the stabilized camera, and the screen on camera will prompt to enter wireless connection status, then the remote handle can control the camera wirelessly.




### Operation

#### Power button

**Long press for 1s:** Power ON/ OFF  
**Long press for 8s:** Power off forcibly


### Single tap:

1. Switch among video/ Photo mode/ Recently used function
2. Return to the previous menu



### Joystick

**Push:** Control the movement of the tilt and pan axes




### Gimbal mode button

**Single tap:** Follow mode/All follow mode/Pan mode (Switch in turn)

**Double tap:** Recenter

**Triple tap:** Enter/Exit selfie mode

**Press and hold:** Enter lock mode



## Shutter button


**Single tap:** Start/stop recording/Take photo



## Zoom button


**Slide up (T):** zoom in

**Slide down(W):** zoom out



## Screen Operation












Shooting mode














Battery level







Video duration/  
number of photos  
can be stored for  
reference























		<b>Swipe from right to left:</b> <ul style="list-style-type: none"> <li>Switch among different shooting modes and set corresponding mode parameters.</li> <li>Swipe up or down to switch among photo/ video/ slow motion/ timelapse/ panoram a mode, tap to enter corresponding mode setting</li> </ul>
	Photograph	Users can set aspect ratio of photos and countdown to take photo. Optional aspect ratio: 4:3 / 16:9 Optional countdown time: Off/ 3s/ 5s/ 7
	Video	Users can set video resolution and FPS. Optional video resolution: 4K / 2.7K / 1080P Optional FPS: 24 / 25 / 30 / 48 / 50 / 60 /120
	Slow motion	Users can shoot slow-motion video. Optional ratio of slow-motion recording: 4K 2X/1080P 4X/720P 8P
	Time-lapse photography	Users can choose static, motion timelapse, or hyperlapse and enter shooting interface after chose, and set shooting interval and duration by tap the bottom of the interface. Optional video resolution: 4K / 2.7K / 1080P  When you choose motion timelapse, tap  to set start position  tap  again to set end position  , tap  to delete position.
	Panorama mode	Users can choose different panorama modes:2×2/3×3/180°  <b>2×2:</b> two images above and two below combine to one picture <b>3×3:</b> 3 images above in every three layers combine to one picture <b>180° :</b> 3 lateral images combine to one picture

		<b>Swipe up:</b> <ul style="list-style-type: none"> <li>Enter gimbal control interface.</li> <li>Users can recenter gimbal / switch to selfie mode / modify follow sensitivity / switch working modes.</li> </ul>
(1) Gimbal follow mode setting		Tap to recenter, lens return to center and keep towards front or back as before.
		Follow mode
		All follow mode(FPV)
		Pan mode
(2) Selfie mode		Camera horizontally rotate 180° to shoot, which can be used to take selfie.

		<b>Swipe from left to right:</b>  <b>*Available only for USB-C connection</b> <ul style="list-style-type: none"> <li>• Enter the album (Swipe down to exit)</li> <li>• Swipe left/right to view the previous/next item. Swiping left on the most recent item will exit the album.</li> </ul>
	Play	Tap to play the current video
	Favorite	Photos and videos which are marked as like, can be viewed in album [ Favorite ] after connected Feiyu Cam App. Tap to unmark.
	Haven't been marked as favorite yet	Tap to mark it as favorite.
	Delete	Delete the current picture or video.

		<b>Swipe down:</b>  <b>*Available only for USB-C connection</b> <ul style="list-style-type: none"> <li>• Enter setting interface, swipe up to return the previous menu.</li> <li>• Swipe to left / right to switch among different settings.</li> </ul>
(1) Mode setting		Mounting mode
		Handheld mode
		Swipe to left / right to get more settings
		Display battery level
		Turn on/off camera Wi-Fi

(2) System		Anti-flicker setting
		Key tone on /off
		Display remaining storage spaces, tap to show format option.
		Auto power off setting
		Enter calibration. When camera is not level, users can use it to fix. Place the product on a stable horizontal plane such as table, and follow the prompts on the screen to operation.
		Average metering
		Spot metering is available
		Move settings, users can switch languages / reset system parameters / view device information ( firmware version, SN code, etc.)/motor calibration
(3) Viewing angle		Super wide angle
		Wide viewing angle
		Narrow viewing angle
(4) Face tracking		Turn on/off face tracking( available in photo, video and slow motion modes)

(5) Beauty		Open beauty
		Close beauty ( available in photo modes)
(6) Image quality		Super high quality
		High quality ( available in video and slow motion modes)
(7) Display		Full screen display
		Normal display
(8) Professional / Normal mode		Professional Mode
		Normal mode
		After switch to professional mode, users can tap <b>PRO</b> icon to set the related parameters.

Shooting mode	PRO mode				
Settings	Image Format	White balance	Exposure	Color	Volume
Photograph	√	√	√		
Video		√	√	√	√
Slow motion		√	√	√	
Time-lapse photography		√	√	√	
Panoramic photo	√	√	√		






**Image Format:** Select save format (JPG or J+R) for photo

**White balance:** Select a preset white balance mode or set color temperature manually



**Exposure:** Set ISO, shutter speed or exposure compensation


**Color:** Switch between normal color and Fy-log color ( Which is advantageous for postproduction color modulation)

**Volume:** Set video volume

(9) Brightness		High brightness
		Normal brightness
		Low brightness
(10) Saving		Save video
		Save photos and video

**Indicator light instructions**

Indicator light	Indicator status		Instructions	Status
	Photo indicator	Battery indicator		
 Green light	Flash once	–	Photograph	Power on
	Keeps flashing	–	Video	
	–	Constant green light	Finished charging	
 Red light	–	Battery indicator keeps on	Charging	Power off



## Specifications

<b>Product name</b>	<b>Remote Handle for Feiyu Pocket 3</b>
Product model	FeiyuVCAM3SRH
Battery Capacity	750mAh
Charging Time	About 1.2h
Weight	About 73g
Product Size	105.3*30.8*23.1mm

## Notice

1. Make sure motor spinning is not blocked by external force when the product is power on.
2. The product DO NOT contact water or other liquid if the product is not mark waterproof or splash-proof.  
Waterproof and splash-proof product DO NOT contact sea water or other corrosive liquid.

3. DO NOT disassembly the product except marked detachable. It need send to FeiyuTech after-sales or authorized service center to fix it if you accidently disassembly and cause abnormal work. The relevant costs are borne by user.
4. Prolonged continuous operation may cause the product surface temperature to rise, please operate carefully.
5. DO NOT drop or strike the product. If the product is abnormal, contact Feiyu After-sales support.

## Find More Features

### Facebook



### Youtube



### Twitter



## CUSTOMER SUPPORT

This document is subject to change without notice.

If you have any questions about this document, please contact us by the following ways.

**Manufactured by:** Guilin Feiyu Technology Incorporated Company

Website: [www.feiyu-tech.com](http://www.feiyu-tech.com)  
Tel: +86 773-2320865  
E-mail: [support@feiyu-tech.com](mailto:support@feiyu-tech.com)



## Documents / Resources

 <p>FeiyuTech Remote Handle for Feiyu Pocket 3</p>	<p><a href="#">FeiyuTech Remote Handle for Feiyu Pocket 3</a> [pdf] Instructions Remote Handle, Feiyu Pocket 3, Remote Handle for Feiyu Pocket 3, Remote</p>
---	--

## References

- [FeiyuTech - Official Website](#)
- [Teaching video](#)

Manuals+.