



## FEKER IK85Plus Plus Mechanical Keyboard Review Instructions

[Home](#) » [FEKER](#) » FEKER IK85Plus Plus Mechanical Keyboard Review Instructions 


### FEKER IK85Plus Plus Mechanical Keyboard Review Instructions



#### Contents

- 1 [Product parameters](#)
- 2 [Switch indication instructions](#)
- 3 [Lighting effect description](#)
- 4 [Explanation of Sleep Mechanism](#)
- 5 [Mode Connection Description](#)
- 6 [Key composite function key description](#)
- 7 [Key composite function key description](#)
- 8 [Documents / Resources](#)
  - 8.1 [References](#)
- 9 [Related Posts](#)

## Product parameters



**Product brand:** FEKER

**Product name:** IK85Plus

**Product structure:** Leaf spring Gasket structure

**Product size:** 348.3×143.8×44mm

**Product weight:** 920g

**Number of keys:** 83Keys

**Matrix:** Full key without impact

**Connection method:** Wired USB/Bluetooth/2.4G

**Interface:** Keywire separated typec interface


**Battery capacity:** 4000mAh

**Backlight:** RGB (18 sets of light effects)

**Key cap:** MOA PBT three piece key cap

**Compatibility:** Windows 7/8/9/10/11/Mac/Linux//Android/IOS

## Switch indication instructions



**MAC mode:** Switch to MAC mode

**WIN mode:** Switch to Win mode

**Push up:** 2.4G mode

**Middle:** USB mode, factory default

**Push down:** Bluetooth mode

**CAPS indicator light:** CAPS key blue light indication

**Lock win indicator light:** WIN key blue light indication

**Charging indicator light:** When charging, the FN button's red light is on and off when fully charged, and the red

light flashes quickly when the battery is low

## Lighting effect description

1. After powering on, the light turns on and the white light runs around the keyboard, and the tail turns off. After running all the buttons, the light state before powering off is restored.
2. The lighting order of the light mode is from top to bottom in the table, and after switching the mode, there is OFF.
3. 18 lighting effects

## Explanation of Sleep Mechanism

1. Deep sleep: After 10 minutes of keyless operation on the keyboard, it will be in deep standby mode, with Bluetooth disconnected and dormant. Press any button to wake up the keyboard backlight and reconnect to Bluetooth;
2. Power saving sleep: After 2 minutes of keyless operation on the keyboard, the backlight turns off. Press any button to wake up the keyboard backlight and connect back to Bluetooth;

## Mode Connection Description

### Bluetooth Profile Connection

**Bluetooth name: FEKER IK85-1, FEKER IK85-2, FEKER IK85-3**

1. **FN+Q**: Short press to switch to Bluetooth 1, long press to pair Bluetooth 1
2. **2FN+W**: Short press to switch to Bluetooth 2, lang press to pair Bluetooth 2:
3. **FN+E**: Short press to switch to Bluetooth 3, long press to pair with Bluetooth 3;

**Operation:** Alter the keyboard is turned on, press and hold FN+Q/W/E to enter Bluetooth mode. Long press and hold the FN+Q/W/E combination key for 35, and the keyboard will enter the code checking state. The Q/W/E indicator light will flash quickly and white, and the indicator light will remain on when connectedAfter being unable to find the paired device for 30s, the exit code matching mode light turns off and the keyboard enters sleep

### 4G mode connection (Short press to switch to 2.4G, long press to pair with 2.4G)

Operation: After the keyboard is turned on, press FN+4 to enter 2.4G mode, and then press the FN+4 combination key for 35 to enter pairing mode. After inserting the receiver, the R indicator light will flash quickly and white. Once pairing is successful, exit pairing, The mode light remains on for 2 seconds, and after 30 seconds when the paired device cannot be found, the exit code matching mode light turns off, and the keyboard enters sleep.

## Key composite function key description

Combination button	WIN function	MAC function (single press trigger)	Describe
FN+F1	This computer	Screen brightness decrease	Flip the switch to select MAC/WIN
FN+F2	Homepage	Screen brightness increase	
FN+F3	Calculator	Multitasking controller	
FN+F4	Player	Program List	
FN+F5	Previous song	Nothing	
FN+F6	Next song	Nothing	
FN+F7	Play Pause	Previous song	
FN+F8	Suspend	Play Pause	
FN+F9	Mute	Next song	
FN+F10	Volume-g	Mute	

### Key composite function key description

Combination button	WIN function	MAC function (single press trigger)	Describe
FN+F11	Volume+	Volume-	Flip the switch to select MAC/WIN
FN+F12	Mailbox	Volume+	
FN+BAKSPACE	Long press and hold for 3S to reset	Long press and hold for 3S to reset	Keyboard backlight flashing three times with white light
FN+ \ /	Keyboard backlight effect switching	Keyboard backlight effect switching	(Order: Colorful, Red, Orange, Yellow, Green, Blue, Purple, White)
FN+Enter	Keyboard backlight effect switching	Keyboard backlight effect switching	18 default light effects follow the current
FN+Space	Check battery level (wireless mode) The power supply from the lower battery is effective	Check battery level (battery power is valid in wireless mode)	Press the combination key Fn+space, the backlight will turn off, and the number keys 1 to 0 will light up the light displays the proportion of battery power, for example: 1 is on, indicating 10% battery power, 1 and 2 on, indicates 20% battery capacity. And so on. (Below 30% in red,
FN+Home	END	END	Below 50% yellow, above 50% green). —

Combination button	WIN function	MAC function (single press trigger)	Describe
FN+DEL	INS	INS	—
FN+L	Keyboard backlightswitch	Keyboard backlight switch	—
FN+WIN-L	Lock WIN	Nothing	WIN bright blue light
FN+→	Light speed slows	—	When in the extreme gear position, the up, down,
	down		left, and right lights flash three times to indicate.
FN+←	Accelerated light speed	—	When in the extreme gear position, the up, down, left, and right lights flash three times to indicate.
FN+↑	Light brightness +	—	When in the extreme gear position, the up, down, left, and right lights flash three times to indicate.
FN+↓	Light brightness-	—	When in the extreme gear position, the up, down, left, and right lights flash three times to indicate.
FN+,<	Accelerated light effect speed	Accelerated light effect speed	When in the extreme gear position, the up, down, left, and right lights flash three times to indicate.
FN+.>	Slow down light effect speed	Slow down light effect speed	When in the extreme gear position, the up, down, left, and right lights flash three times to indicate.



## Documents / Resources

	<a href="#">FEKER IK85Plus Plus Mechanical Keyboard Review</a> [pdf] Instructions IK85Plus Plus Mechanical Keyboard Review, IK85Plus, Plus Mechanical Keyboard Review, Mechanical Keyboard Review, Keyboard Review, Review
--	---

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.