

Feniex C-4010 4200 Mini Controller



# Feniex C-4010 4200 Mini Controller Instruction Manual

[Home](#) » [Feniex](#) » Feniex C-4010 4200 Mini Controller Instruction Manual 

## Contents

- [1 Feniex C-4010 4200 Mini Controller](#)
- [2 SAFETY REGULATIONS & WARRANTY](#)
- [3 SPECIFICATIONS](#)
- [4 EQUIPMENT DIMENSIONS](#)
- [5 REMOTE CONTROL INSTRUCTIONS](#)
- [6 BUTTON LEGEND SHEET](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)
- [8 Related Posts](#)



**Feniex C-4010 4200 Mini Controller**



#### 4200® MINI CONTROLLER



#### 4200 MINI CONTROLLER C-4010

**Feniex Product Copyrights** This price List and the mentioned Feniex products include or describe copyrighted Feniex material. Laws in the United States and other countries preserve for Feniex Industries and its licensors certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Feniex and its licensors contained herein or in the Feniex products described in this Price List may not be copied, reproduced, distributed, merged or modified, transmitted, transcribed, stored in retrieval system or translated into any language or computer language, in any form or by any means, without prior written permission of Feniex Industries, Inc.. Feniex and the stylized Feniex logo are registered in the U.S. Patent & Trademark Office.

#### SAFETY REGULATIONS & WARRANTY

## Safety Regulations

- The following provides all the information necessary to safely operate the previously listed products of Feniex Industries, Inc. Please read this manual thoroughly before installing or operating your new product in order to prevent any damage or injury. Failure to follow the listed instructions in this manual may result in damage to your products or personal injury.
- Proper installation of this product requires good knowledge of automotive systems, electronics and procedures.
- Please guarantee all vital components of the vehicle are not in danger of being damaged by drilling holes necessary for installation. Check all sides of the mounting surface before drilling any holes into the vehicle.
- Do not install this product in any way that interferes with the deployment of the air bag. Doing so may damage the effectiveness of the air bag and can lead to serious personal and vehicle injury. The installer will assume full responsibility of proper installation of the new unit.
- Please clean the mounting surface before installation of the unit when using tape, brackets, magnet, Velcro or suction cups.
- The product's ground wire must be connected directly to the Negative (-) battery post for effective use of the unit. Please follow all wiring guidelines provided to guarantee long lifespan and productivity. Failing to follow these instructions may result in damage to the product.

## Warranty

- Feniex Industries' speakers, sirens, rocker panels, AM600 Beacons, Torch Lights, AI lightbars, AI Cubes, AM900 Work Lights and controllers are warrantied for 2 years from the manufacturing date. In addition, all other products are warrantied for 5 years from the manufacturing date.
- If a warranty problem occurs, please contact customer support at 1.800.615.8350 or visit the web site at [www.Feniex.com](http://www.Feniex.com) . If the product needs to be returned for repair or replacement, call our customer support line to receive a return merchandise authorization number.
- Operational times are from 10 a.m. to 5 p.m. central time, Monday through Friday. Please do not send in product without contacting support first for a RMA number.

## Service After Expiration

- Feniex Industries will still provide service for all products after expiration of the warranty. For any issues, call the customer support line. In some instances it may be necessary for the product to be shipped, freight prepaid and insured for loss or damage to Feniex headquarters.
- **Warning!** Utilizing non-factory screws and mounting brackets may result in loss of warranty coverage.

## Copyright

This instruction manual and the Feniex products described in this instruction manual may include or describe copyrighted Feniex material. Laws in the United States and other countries preserve for Feniex Industries and its licensors certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Feniex and its licensors contained herein or in the Feniex products described in this instruction manual may not be copied, reproduced, distributed, merged or modified in any manner without the express written permission of Feniex Industries, Inc.

## Feniex Product Copyrights

The products described in this document are the property of Fenieux Industries, Inc. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement. Products and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the product or documentation may be reproduced, transmitted, transcribed, stored in retrieval system or translated into any language or computer language, in any form or by any means, without prior permission from Fenieux Industries, Inc.

**SPECIFICATIONS**

|            |                   |          |                    |
|------------|-------------------|----------|--------------------|
| Dimensions | 4" x 2.8" x 0.75" | Amps     | 3.5A per Button    |
| Warranty   | 2 years           | Max Draw | 750mA              |
| Voltage    | 10-18 V DC        | Buttons  | On/Off & Momentary |


**EQUIPMENT DIMENSIONS**



**INCLUDED MOUNTING:**



## REMOTE CONTROL INSTRUCTIONS



## WIRING DIAGRAM

|       |                 |        |                 |
|-------|-----------------|--------|-----------------|
| Black | Ground, 12V-    | Blue   | Button #3, 12V+ |
| Red   | Positive, 12V+  | Yellow | Button #4, 12V+ |
| Green | Button #1, 12V+ | Brown  | Button #5, 12V+ |
| White | Button #2, 12V+ | Gray   | Button #6, 12V+ |

### POWER

To power the unit, extend the red wire to a 12v (+) post. Extend the black wire to the ground post of the vehicle's battery.

### AUTO POWER ON

The 4200 Mini can be programmed to power on automatically when power is applied to the red wire, or it can remain off until the power button is pressed. To toggle this mode:

1. While the unit is powered, but turned off, press and hold the power button until a beep is heard.
2. The mode has been toggled. To change it again, repeat step 1.

### MOMENTARY

You can program each of the 6 outputs to operate as either latching or momentary functionality. To toggle this mode:

1. While the unit is powered, but turned off, press and hold the button you wish to program.
2. While holding the button from step 1, press and hold the power button until a beep is heard.
3. The mode has been toggled. To change it again, repeat steps 1 & 2.

## ALT. WIG-WAG

You can program outputs 1 & 2 to operate as an alternating wig-wag flasher. To toggle this mode:

1. While the unit is powered, but turned off, press and hold both button #1 and button #2.
2. While holding the buttons from step 1, press and hold the power button until a beep is heard.
3. The mode has been toggled. To change it again, repeat steps 1 & 2.

## WIG-WAG FUNCTIONS


- When the wig-wag function is active, button #1 activates and deactivates the mode while button #2 changes the selected flash patterns.
- Wig-wag mode will override the momentary functionality while it is active in the programming.

## BUTTON LEGEND SHEET

|           |            |             |         |        |               |         |           |             |         |            |             |        |
|-----------|------------|-------------|---------|--------|---------------|---------|-----------|-------------|---------|------------|-------------|--------|
| BLACK OUT | HIDE-A WAY | GUN LOCK    | CLEAR   | POWER  | SLOW          | CAB     | AUX 4     | LOW POWER   | SIREN   | MANUAL     | PLOW LIGHT  | ←      |
| BUMPER    | DOOR       | GUN         | STEP    | KILL   | FAST          | TRUNK   | AUX 5     | LBAR POWER  | Q-SIREN | AIR HORN   | WORK LIGHT  | ↔      |
| INVERT    | GRILL      | LOCK        | WIG WAG | DIM    | TRAFFIC       | TOW     | AUX 6     | LBAR FRONT  | WAIL    | MECH       | MAP LIGHT   | →      |
| CHARG     | DECK       | RAPID FLASH | HAZARD  | ON/OFF | BRAKE         | ALARM   | CODE 1    | LBAR REAR   | WAIL 2  | HANDS FREE | SEARCH      | FLASH  |
| STAND BY  | DASH       | FLASH MODE  | VIDEO   | AMBER  | BACK UP       | RADIO   | CODE 2    | ALLEY LEFT  | YELP    | PHASER     | DOMES       | WARN   |
| STROBE    | FRONT      | PATTERN     | CAMERA  | WHITE  | K9            | PURSUIT | CODE 3    | ALLEY RIGHT | YELP 2  | STING      | FLOOD       | LEFT   |
| PREEMP    | REAR       | MODE        | COMP    | GREEN  | SIDE CUT      | WARN    | MODE 1    | FRONT CUT   | HI-LO   | TAP 1      | FRONT FLOOD | RIGHT  |
| LEFT      | SIDE       | UPPER       | PC      | RED    | LICENSE PLATE | AUX 1   | MODE 2    | REAR CUT    | HORN    | TAP 2      | REAR FLOOD  | CENTER |
| RIGHT     | FOG        | LOWER       | RADAR   | BLUE   | LED           | AUX 2   | MODE 3    | RIGHT CUT   | HORN 1  | SPOT       |             |        |
| CENTER    | CRUISE     | TAIL        | MAIN    | RESET  | AREA          | AUX 3   | TAKE DOWN | LEFT CUT    | HORN 2  | SPOT LIGHT |             |        |

Feniex Industries, Inc.

1.800.615.8350 / [feniex.com](https://www.feniex.com)

|  |  |
|--|--|
|  | <p><a href="#">Feniex C-4010 4200 Mini Controller</a> [pdf] Instruction Manual</p> <p>C-4010 4200 Mini Controller, C-4010, 4200 Mini Controller, Mini Controller</p> |
|--|--|

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.