



FIBERBUILT T-660-4X10 Performance Turf Series Tee Box Instructions

[Home](#) » [FIBERBUILT](#) » FIBERBUILT T-660-4X10 Performance Turf Series Tee Box Instructions 



Performance Turf series
Tee Box – 10'x4'
T-660-4X10



Ball tray not included, sold separately

Contents

1 Parts & assembly

2 Documents / Resources


2.1 References

Parts & assembly


Please check your box for accuracy.
All of these pieces should be included.

ITEM	PART NUMBER	QTY.
A	TLCM-C-2	4
B	TLCM-E-2	6
C	TLCM-P-2	10
D	TLCM-P-4	4
E	TLCM-PINS50	1 Bag
F	660-TL-4X10	1

RUBBER BASE



HARDWARE



GRASS PANELS




F
10'x4' Performance Turf (x1)

FiberbuiltGolf.com


1. Ensure the ground is properly prepared for placement of the rubber base. The surface should be firm, packed and level. Concrete, asphalt, patios or decking are ideal. (Do not place on grass.)

Place the rubber base pieces (A, B) on the ground together as shown.



2. Lay the Performance

Turf (F) on top of the base area to fit the frame.




NOTE: We ship our turf folded in the box for the most expedient shipping. During transit, the turf pieces may curl slightly. If your turf is curled upon delivery, we recommend laying the turf pieces flat in the sun for a couple of hours to allow them to relax and flatten prior to laying them down on the base.

3. Secure rubber base pieces (A, B) together by pushing Connectors into adjacent holes in the sections.




2-Pin Connectors (C) for side connections



Optional Step: For increased security and stability, install and secure Connectors with pins from underneath as you assemble the base pieces. (If the mat will be regularly moved or disassembled, we recommend skipping the use of the pins.)

Steps for securing the pins:

- As you set base pieces next to each other, lift up the corners of the rubber base pieces and place a plastic push pin (E) into the holes from underneath.
- From the top, push the rubber 2-pin (C) or 4-pin (D) Connectors into position, guiding them onto the plastic push pins.
- Gently tap with a hammer until the connectors are flush with the base surface.



4. Insert real tees anywhere on the Performance Turf to practice all kinds of tee shots.



Double the Life of Your Warranty Today for Free

For a free one-year extension to our standard warranty, exclusive access to insider deals, new product information and much more, register your mat today at:

FiberbuiltGolf.com/register

Be sure to select the following:

Performance Turf series

Tee Box – 10'x4'

SKU#: T-660-4X10

Documents / Resources



[FIBERBUILT T-660-4X10 Performance Turf Series Tee Box](#) [pdf] Instructions

T-660-4X10 Performance Turf Series Tee Box, T-660-4X10, Performance Turf Series Tee Box, T
urf Series Tee Box, Tee Box

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.