



FIDO2 Fingerprint Security Key User Guide

[Home](#) » [fido](#) » FIDO2 Fingerprint Security Key User Guide 

fidoTM

CERTIFIED

KEY ACTIVATION
Vin CSS FIDO2® Fingerprint



Contents

1 INTERGRATE KEY TO COMPUTERS:

2 SET UP A PIN – FINGERPRINT

3 LED NOTIFICATION

4 Documents / Resources

4.1 References

INTERGRATE KEY TO COMPUTERS:

- USB: Use a USB type C cable to connect directly.
- BLE: Keep your finger still on the scanner for around 4s and stop once the LED turn blue, the pairing process is similar to conventional Bluetooth pairing, The pairing code is the last sequence (5 or 6 digits) of the serial code displayed on the back of the security key.
- NFC: Use an NFC reader.

NOTE: For the first time use, requires the user to make a direct connection via a USB type C cable.

SET UP A PIN – FINGERPRINT

Select Start > Settings > Account > Sign-in options > Security Key, choose Manage.

- Input PIN :From 4 to 63 characters, including letters (lowercase, uppercase), digits and symbols.
- Establish a fingerprint: As the white LED flashes, put one finger on the sensor. Once the LED turn green, move your finger away from the sensor and repeat the process 5 times.

REGISTRATION AND LOG IN GUIDE

Microsoft 365 account with Vin CSS FIDO2® Fingerprint Authenticator

1. Registration

- Select “My Microsoft account, open ‘Security, choose “Additional Security Options’
- Select “Add a new way to sign in or verify, choose ‘Use a security key’
- The set-up process will be presented on the device screen, when the key flashes with white LED, scan your finger

02. Password less account sign in/log in

- Open Microsoft log in site
- Select “Sign in option’
- Choose “Sign in with Windows Hello or a security key, when the security key shows a white LED, scan your fingerprint

Please scan the provided QR Code for guidance with Facebook, Google, Twitter etc accounts or on other platforms

supported platforms



<https://www.youtube.com/watch?v=ITdBF5qAtzc>

LED NOTIFICATION

LED SIGNALS	DEFINITION
Red flashes (3 times)	Charging is necessary because the battery is below 20 %
Green flashes (continuous)	Using Bluetooth
Blue flashes (flickering)	Pairing via Bluetooth
White flashes	Request for interaction with the fingerprint sensor
Green flashes (during scanning process)	Scan successfully
Red flashes (during scanning process)	Scan unsuccessfully
Amber	Charging (the battery is below 90%)
Green (charging)	Battery above 90%
Purple	The key is within the NFC field



BE ADVISED: The product is not waterproof

The above guides are for the W support.fido2@vincss.net for on other platforms.
endows OS. Please contact Vines via email:

CONTACT REFERENCES

VINCSS INTERNET SECURITY SERVICES JOINT STOCK COMPANY

- Floor 20A, Vincom Center, 45A Ly Tu Trong, Ben Nghe Ward, District 1, Ho Chi Minh City, Vietnam
- Email: sales@vincss.net
- Website: <https://passwordless.vincss.net>

Documents / Resources

	fido FIDO2 Fingerprint Security Key [pdf] User Guide FIDO2, FIDO2 Fingerprint Security Key, Fingerprint Security Key, Security Key, Key
---	---

References

- [User Manual](#)