

fingers SwiftCharge Rechargeable Wireless Mouse



fingers SwiftCharge Rechargeable Wireless Mouse User Guide

[Home](#) » [fingers](#) » fingers SwiftCharge Rechargeable Wireless Mouse User Guide 

Contents

- [1 fingers SwiftCharge Rechargeable Wireless Mouse](#)
- [2 Warnings & Safety Instructions](#)
- [3 Care and Maintenance](#)
- [4 In the box](#)
- [5 On-board Controls](#)
- [6 Charging](#)
- [7 Wireless Connection](#)
- [8 Product Specifications](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)



fingers SwiftCharge Rechargeable Wireless Mouse



Warnings & Safety Instructions

1. Do not place the mouse near the heat sources such as radiators, fire, stoves, light candles and other apparatus that produce heat.
2. Focus on your safety and that of others. We recommend keeping it dry and not allow the mouse to get wet or exposed to moisture/rain, which may present the possibility of fire or shock to yourself or others
3. Use only those accessories supplied by FINGERS.
4. It is recommended to refer all servicing to qualified personnel. Servicing is required when the keyboard has been damaged in any way. Any evidence of any attempt to open and/or alter the device, including any scratch, peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.

CAUTION This device contains small parts which are hazardous to children. Keep it away from children of age 3 and under.


Care and Maintenance

1. Switch off the mouse before cleaning it.
2. Use soft, damp cloth to clean the surface.
3. Do not use any chemicals, solvents, or cleaning solutions containing alcohol, ammonia or abrasives.
4. Do not allow any liquid to enter into any of the openings.

In the box

- 1 x FINGERS Swiftcharge
- 1 x Type-C Charging Cable
- 1 x USB Receiver
- 1 x Quick Start Guide
- 1 x Brand Note

On-board Controls



1. Left and Right Buttons
2. Scroll Wheel
3. DPI button (to change cursor speed – (800 / 1200 / 1600 CPI)
4. Forward/Reverse switch
5. On/Off switch
6. Nano USB Receiver storage
7. Type-C charging port

Charging

- Plug the Mouse into a USB port using Type-C charging cable provided.
- While charging, the LED turns red. Once completely charged, it turns off.
- Allow up to 2 hours to completely charge the mouse Please note: Use only USB to Type-C cable for charging.

Wireless Connection

You can use Mouse wirelessly using its USB Receiver .



- Step 1: Switch on the Mouse.

- Step 2: Take out the USB receiver from back side of Mouse.
- Step 3: Plug the USB Receiver into a USB port of your PC/Laptop. And, you're good to go!


Product Specifications

Parameters	SwiftCharge
Technology	Wireless Optical Technology
Button	5 Buttons with Scroll Wheel
Power Source	3.7 V 500 mAh Rechargeable Battery
Wireless Effective Range	Up to10m
Charging Time	Up to 2 hours
Battery Backup Time	Up to 25 days
Resolution	800/ 1000/ 1200/ 1600 DPI (Changeable)
Interface	use Port (2.4 GHz use nano Receiver)
Switch Life	5 million life cycles
System Requirements	OS Support; Microsotr Windows- I macOS I
Linux I Chrome OS	
Dimensions	109 (L) x 60 (W) x 32 (H) mm
Weight	60g
Colour	Matte Black

fingers.co.in | Ver.1.0.0

- Tested under ideal conditions and varies depending on usage.
- Images shown may vary from actual product.
- Specifications, features and appearance are subject to change without notice.
- All logos, brands, trademarks and product names are properties of their respective owners.
- Product warranty is governed by warranty terms mentioned on www.fingers.co.in
- This product falls under e-waste (Management & Handling) Rules, 2011. For proper disposal method, visit our website www.fingers.co.in

Documents / Resources

	fingers SwiftCharge Rechargeable Wireless Mouse [pdf] User Guide 2024-01-13, 1705129714, SwiftCharge Rechargeable Wireless Mouse, SwiftCharge, Rechargeable Wireless Mouse, Wireless Mouse, Mouse
---	--

References

- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.