FISHER & PAYKEL
C1302DTB4
30cm 2 Zone
Induction Hob
with SmartZone





FISHER AND PAYKEL CI302DTB4 30cm 2 Zone Induction Hob with SmartZone User Guide

Home » FISHER and PAYKEL » FISHER AND PAYKEL Cl302DTB4 30cm 2 Zone Induction Hob with SmartZone User Guide [™]

Contents

- 1 FISHER AND PAYKEL CI302DTB4 30cm 2 Zone Induction Hob with
- **SmartZone**
- **2 Product Usage Instructions**
- **3 DIMENSIONS**
- **4 FEATURES & BENEFITS**
- **5 SPECIFICATIONS**
- 6 FAQs
- 7 Documents / Resources
 - 7.1 References

FISHER & PAYKEL

FISHER AND PAYKEL Cl302DTB4 30cm 2 Zone Induction Hob with SmartZone



Specifications

- Accessories (sold separately): Joiner kit Part 534731 (required to join two cooktops)
- Cleaning: Flat easy clean glass surface
- Controls: Auto cut-off timer for each zone, Minute timer, Soft-touch electronic controls, Touch and slide controls
- **Performance:** Auto heat reduce, Gentle heat, Heat settings, Induction cooking technology, PowerBoost, SmartZone, Zone bridging
- Power requirements: Supply voltage 220 240 V
- Product dimensions: Depth 530 mm, Height 54 mm, Width 300 mm
- Safety: Individual hot surface indicators, Keylock, Pan detection system, Safety time out, Spillage auto off, Surface hot indicators
- Warranty: Parts and labor
- Zone ratings: Left front 2100W, Left front zone (PowerBoost set) 3700W, Left rear 2100W, Left rear zone (PowerBoost set) 3700W
- Zones: Number of zones 2
- **SKU**: 81975

Product Usage Instructions

Complementary Design

The hob features a subtle black glass and durable matte black detailing designed to pair with the Minimal style Series 7 Ovens for a cohesive kitchen design.

Enhanced Features

Utilize PowerBoost for very high heat and GentleHeat for very low heat. The integrated timer ensures precise cooking results.

Instant Response

Adjust the temperature from boil to simmer instantly with Touch&Slide controls for efficient cooking.

Easy Cleaning

The flat easy clean glass surface makes cleaning hassle-free after cooking sessions.

Superior Efficiency

Induction cooking is energy-efficient as it heats only the cookware, not the hob surface, reducing heat wastage.

Large, Flexible Cooking Area

Use SmartZone to link two cooking zones for handling larger pans and food items like whole fish with ease.

Enjoy the ability to create a large cook zone with SmartZone, or to match with a two-burner gas hob.

- Immediate heat response and extremely accurate temperature control
- · Cooktop remains cool to touch until a pot or pan is placed on the surface
- PowerBoost activates a very high heat, bringing liquid to boil in less than a minute
- Easily control each cook zone with Touch&Slide, including pairing cook zones to create a large SmartZone

DIMENSIONS

- Height 54 mm
- Width 300 mm
- **Depth** 530 mm

FEATURES & BENEFITS

Complementary Design

The subtle black glass and durable matte black detailing are designed to pair with the Minimal style Series 7 Ovens. With premium styling and detailing, these hobs seamlessly blend with other appliances for a cohesive, considered kitchen design.

Enhanced Features

PowerBoost and GentleHeat deliver either very high or very low heat, fast. Perfect for specialised cooking tasks such assearing meat and melting chocolate. An integrated timer ensures a great result every time

Instant Response

Go from a boil to a simmer in seconds. Touch&Slide controls react immediately when you adjust the temperature so you don't waste time in the kitchen.

Safer Choice

Induction hobs only start heating your pot or pan once you've placed it on the ceramic surface and stop as soon as you remove it — so you don't have to worry about curious little fingers or leaving a cook surface on.

Easy Cleaning

The surface around your cookware stays cool when you cook – preventing baked-on spills and making cleaning up a breeze. The ceramic hob surface, including anodised detailing for durability, just needs a quick wipe after use to maintain its good looks.

Superior Efficiency

Less heat is wasted during induction cooking because only the cookware is heated, not the hob surface. This makes induction cooking more energy-efficient than electric or gas hobs.

Large, Flexible Cooking Area

SmartZone links two cooking zones and controls them as one, giving you the flexibility to use large pans and griddles and easily handle bigger food items such as a whole fish.

SPECIFICATIONS

Accessories (sold separately)

• Joiner kit Part 534731 (required to join two cooktops)

Cleaning

• Flat easy clean glass surface •

Controls

- · Auto cut-off timer for each zone ·
- Minute timer •
- · Soft-touch electronic controls ·
- Touch and slide controls •

Performance

- · Auto heat reduce ·
- Gentle heat •
- · Heat settings 9
- Induction cooking technology •
- PowerBoost •
- SmartZone •
- · Zone bridging ·

Power requirements

• Supply voltage 220 - 240 V

Product dimensions

- Depth 530 mm
- Height 54 mm
- Width 300 mm

Safety

- Individual hot surface indicators •
- Keylock •

- Pan detection system •
- · Safety time out ·
- · Spillage auto off ·
- Surface hot indicators

Warranty

· Parts and labour 5 years

Zone ratings

- · Left front 2100W
- Left front zone (PowerBoost set) 3700W
- Left rear 2100W
- Left rear zone (PowerBoost set) 3700W

Zones

• Number of zones 2

SKU

81975

The product dimensions and specifications in this page apply to the specific product and model. Under our policy of continuous improvement, these dimensions and specifications may change at any time. You should therefore check with Fisher & Paykel's Customer Care Centre to ensure this page correctly describes the model currently available. © Fisher & Paykel Appliances Ltd 2020

Other product downloads available at fisherpaykel.com

- 2D-DWG Induction Cooktop
- 2D-DXF Induction Cooktop
- ArchiCAD-23 Induction Cooktop
- Data Sheet Induction Cooktop
- Service & Warranty
- Installation Guide
- Revit-18 Induction Cooktop
- Rhino-5 Induction Cooktop
- Sketchup-8 Induction Cooktop
- User Guide
- User Guide Induction Cooktop

Where applicable:

All appliances use energy, and energy usage typically generates carbon emissions. Fisher & Paykel
 Appliances' In-use Energy Carbon Emissions Estimate indicates carbon emissions from a product's in-use

- energy. This is calculated either annually or percycle, using the product's market-specific energy label energy consumption data multiplied by the carbon emissions factor for energy in your country or region.
- Our In-use Energy Carbon Emissions Estimate is designed to assist customers in making informed purchasing decisions when comparing different Fisher & Paykel products. For example, a heat pump dryer typically has a lower In-use Energy Carbon Emissions Estimate than a vented dryer.

A PEACE OF MIND SALE

- 24 Hours 7 Days a Week Customer Support
- T 08000 886 605 Wwww.fisherpaykel.com

FAQs

Q: Can I use induction-compatible cookware on this hob?

A: Yes, ensure your cookware is suitable for induction cooking to utilize this hob effectively.

Q: How do I activate the PowerBoost feature?

A: To activate PowerBoost, simply select the desired cooking zone and press the PowerBoost button to bring liquid to a boil quickly.

Q: Is the hob surface safe to touch when not in use?

A: Yes, the hob surface remains cool to touch until a pot or pan is placed on it, ensuring safety during operation.

Documents / Resources



FISHER AND PAYKEL CI302DTB4 30cm 2 Zone Induction Hob with SmartZone [pdf] User Guide

CI302DTB4 30cm 2 Zone Induction Hob with SmartZone, CI302DTB4, 30cm 2 Zone Induction Hob with SmartZone, Induction Hob with SmartZone, Hob with SmartZone, SmartZone

References

- Shop Luxury Kitchen Appliances | Fisher & Paykel USA
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.