Skip to content

Manuals+

User Manuals Simplified.



Contents <u>hide</u>
1 Fitbit Luxe Manual Hard Reset
2 Related Posts



Fitbit Luxe Manual Hard Reset



How to factory reset FITBIT Luxe? How to wipe all data in FITBIT Luxe? How to bypass screen lock in FITBIT Luxe? How to restore defaults in FITBIT Luxe?

The following tutorial shows all method of master reset FITBIT Luxe. Check out how to accomplish Hard Reset by hardware keys and Android settings. As a result your FITBIT Luxe will be as new and your core will run faster.

1. Let's begin by waking up the screen on your FITBIT Luxe. You can do it by tapping on the screen.

Fitbit Luxe Manual Hard Reset User Guide

Home » Fitbit » Fitbit Luxe Manual Hard Reset User Guide 📆



- 2. After you wake up the screen, swipe downwards on the screen until you see the Settings icon.
- 3. Next, tap on the Settings icon.
- 4. Then scroll down and tap on the Device Info option.
- 5. Now scroll down and tap on the Clear User Data.
- 6. Finally, swipe up on the screen, then press on the Hold 3 Sec button for 3 seconds and release to start the resetting process.
- 7. Wait until the resetting process is complete.
- 8. Outstanding job!

Download PDF: Fitbit Luxe Manual Hard Reset User Guide

Manuals+,

- home
- privacy