

FIX IT STICKS Set of Bubble Levels-Scope Jack Instructions

Home » FIX IT STICKS » FIX IT STICKS Set of Bubble Levels-Scope Jack Instructions



Contents


- 1 FIX IT STICKS Set of Bubble Levels-Scope
- **2 SCOPE JACK INSTRUCTIONS**
- 3 Documents / Resources
- **4 Related Posts**



FIX IT STICKS Set of Bubble Levels-Scope Jack




SCOPE JACK INSTRUCTIONS



(Minimum 0.26" clearance)


- 1. Loosen scope ring screws so main tube rotates freely with minimal effort.
- 2. Using thumb screw, attach Scope Jack to rail so lifting arm is positioned under flat section under scope. In case of minimal clearance, it may be required to unscrew clamp



- 3. Using 1/4"driver, rotate lifting arm until it makes contact with flat section on the bottom of scope. Continue applying gentle pressure until scope settles to a level position
- 4. While maintaining light pres- sure on the lifting arm, snug ring screws in a cross pattern Apply manufacturerspecified torque for final tightening

For more Info, Visit fixitsticks.com

Documents / Resources



FIX IT STICKS Set of Bubble Levels-Scope Jack [pdf] Instructions

Set of Bubble Levels-Scope Jack, Bubble Levels-Scope Jack, Levels-Scope Jack, Scope Jack, Jack

Manuals+, home privacy