



FIXED BT8925B Talk Wireless Handsfree User Manual

[Home](#) » [FIXED](#) » [FIXED BT8925B Talk Wireless Handsfree User Manual](#) 



FIXED TALK USER MANUAL

Contents

- [1 BT8925B Talk Wireless Handsfree](#)
- [2 PACKAGE CONTENTS](#)
- [3 HOW TO PAIR AND CONNECT/DISCONNECT HEADPHONE](#)
- [4 CHARGING](#)
- [5 CHARGING SIGNAL](#)
- [6 FUNCTIONALITY](#)
- [7 HOW TO CONNECT TWO DEVICES](#)
- [8 SPECIFICATIONS](#)
- [9 PRODUCT CARE AND MAINTENANCE](#)
- [10 SECURITY MEASURES](#)
- [11 TROUBLESHOOTING](#)
- [12 Documents / Resources](#)
- [13 Related Posts](#)

BT8925B Talk Wireless Handsfree

Thank you for purchasing the wireless handsfree FIXED Talk. The handsfree has top-notch sound and is equipped with modern BT 5.2 technology and the ability to connect two mobile phones. The handsfree can last up to 33 hours of talk time on a full charge. Please read this manual before use.

PACKAGE CONTENTS

1x user manual
1x Handsfree headset FIXED Talk
1x USB-C power cable
2x behind the ear hook

We recommend charging FIXED Talk to full capacity before first use. To charge, simply connect the included or other USB/USB-C cable to a charger or USB outlet on your computer or laptop. The handsfree will start charging automatically.

HOW TO PAIR AND CONNECT/DISCONNECT HEADPHONE

1. Slide the button towards the USB-C connector to turn it on. The LED will start flashing blue and red. FIXED Talk is in pairing mode.
2. Turn on the Bluetooth function on your phone, then search for FIXED Talk.
3. Moving the button away from the USB-C connector automatically disconnects the connection.
4. By sliding the button towards the USB-C connector, it automatically reconnects to the already paired device.

Once the handsfree has been successfully paired with your phone, it is ready for use.

CHARGING

1. Unclip the USB-C connector cap on the top.
2. Plug the USB-C cable into the port on the charging case.

CHARGING SIGNAL

1. If the red LED is lit, FIXED Talk is charging.
2. Once FIXED Talk is fully charged, the LED lights up blue.

FUNCTIONALITY

Power on: slide the button towards the USB-C connector

Power off: Move the button to a position away from the USB-C connector

Receiving a call: 1x click on the MBF button

End call: 1x click on the MBF button


Increase the volume: + button

Decrease the volume: button Dial last dialed number: 2 clicks on the MBF button

To reject a call: long hold the MBF button – approx. 2 seconds

Previous song: Long + button hold approx. 2 seconds

Next song: Long – button hold approx. 2 seconds



HOW TO CONNECT TWO DEVICES

First, pair your first mobile phone with the FIXED Talk handsfree. After successful connection, turn off Bluetooth on the first device. Now pair the FIXED Talk handsfree with the second mobile phone. After successful pairing with the second device, turn on Bluetooth on the first device as well. Both devices should now be connected to the FIXED Talk handsfree. In case of a problem, remove FIXED Talk from your favourite devices in the Bluetooth section and repeat the action.

SPECIFICATIONS

- Version BT: 5.2
- Reach: 10-15 m
- Chipset: BT8925B
- Code: SBC AAC
- Bluetooth protocols: HFP/A2DP/AVRCP/ SBC/AAC
- Frequency range: 20HZ~20KHZ
- Operating wireless frequency: 2.4GHz
- Sensitivity: $103 \pm 3\text{db}$
- Impedance: $32\Omega \pm 10\%$
- Headphone material: ABS/PC
- Battery capacity: 220mAh
- Input: DC 5 V 1 A
- Battery life in use: up to 33 hours
- Standby time: 280 hours
- Charging time: 2.5 hours
- Dimensions: 69*18*29 mm
- Hands-free weight: 13.2 g

NOTES

The product is warranted according to the legal regulations in force in the countries where it is sold. In case of service problems, please contact the dealer from whom you purchased the equipment. FIXED assumes no responsibility for damages caused by improper use of the product.

PRODUCT CARE AND MAINTENANCE

If the device is not used for an extended period of time, it is necessary to charge the battery every two to three months to prevent damage and to ensure that the performance of the device is not reduced. Use a soft cloth to clean the handsfree body.

SECURITY MEASURES

Do not expose the device to rain or snow or immerse it in water. Do not leave the handsfree in the car in the sun. Do not expose the device directly to sunlight or leave it near heat sources.

Do not use the handsfree if it has been subjected to a severe impact, dropped or damaged in any way. Do not disassemble the device, there is a risk of electric shock and/or burns. Do not modify the power cord. Keep the handsfree out of the reach of children. Unauthorized opening or modification of product parts will void the warranty.

- Storage temperature: 0 °C to 35 °C
- Operating temperature: 0 °C to 40 °C

TROUBLESHOOTING

If you have any problems with your product, you can contact our support at www.fixed.zone/podpora



(Applies in countries with separate collection systems for recyclable materials). Old products must not be disposed of with household waste! If the product no longer works, dispose of it in accordance with the applicable regulations in your country. This ensures that old products are recycled in a professional manner and also eliminates negative environmental consequences. For this reason, electrical equipment is marked with the symbol shown here.



This product is CE marked in accordance with EMC Directive 2014/30/EU and RoHS Directive 2011/65/EU. FIXED.zone a.s. hereby declares that this product complies with the essential requirements and other relevant provisions of the EMC 2014/30/EU and 2011/65/EU Directives.

FIXED.zone a.s.

Kubatova 6

České Budějovice 37004

Czech Republic

Documents / Resources



[FIXED BT8925B Talk Wireless Handsfree](#) [pdf] User Manual

FIXTLK2-BK, BT8925B Talk Wireless Handsfree, Talk Wireless Handsfree, Wireless Handsfree , Handsfree