



## FIXED SMILE PRO smart tracker User Guide

[Home](#) » [FIXED](#) » FIXED SMILE PRO smart tracker User Guide 

### SMART TRACKER PRO



#### Contents

- [1 Device description](#)
- [2 Package content](#)
- [3 Getting Started](#)
- [4 Battery replacement](#)
- [5 Using the FIXED SMART application](#)
- [6 Certification and safety information](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)

### Device description

## 1. Multifunction button

- Phone ringing (quick double-click)

## Package content

- FIXED SMILE PRO smart tracker
- Double-sided adhesive tape
- Key ring
- Quick Start Guide

Thank you for purchasing the SMILE PRO tracker of personal belongings. The device is manufactured according to the high standards of the brand and meets the strictest standards for product quality.

## Getting Started

1. Before using the smart tracker, you must download and install the FIXED SMART smartphone It is available free of charge for Android and iOS operating systems in the Google Play Store or AppStore.
2. Open the installed FIXED SMART application, register in one of several ways, and add your SMILE PRO by clicking on the "+" button in the upper right corner. Continue according to the site map in the application.

More information is available at [www.fixed.zone](http://www.fixed.zone) or directly in the application, Help section.

## Battery replacement

1. FIXED SMILE PRO is powered by a high-quality 3V CR2032 battery. In normal use, the battery life is on average 1 year. The charge level can be determined using the application in the detail of the tracker.
2. To replace the battery, carefully remove the back cover of the tracker.
3. Remove the discharged battery and replace it with a new one. Please make sure that the new battery has the same parameters as the original one.
4. Dispose of the old battery in an environmentally friendly manner.

## Using the FIXED SMART application

We are developing the application for you so that you can quickly find your way around it and use it perfectly. Please follow the instructions and accompanying texts in the application to help you set up the tracker ideally for your needs. In case of doubt, you can contact our support through the application or use the Help section. More information is available at [www.fixed.zone](http://www.fixed.zone) or directly in the application, Help section.

- Do not disassemble or otherwise damage FIXED SMILE PRO
- Avoid contact with excessive temperatures (proximity to fire, etc.)
- Operating temperatures: -30 °C -+60 °C
- Frequency range: 2402 MHz – 2480 MHz
- Modulation: GFSK
- Radiofrequency power: s0 dBm

## Certification and safety information


This product bears the CE mark in accordance with the provisions of the R & TTE Directive (1999/5/ EC) and the Dangerous Substances Directive (2011/65/EU). CE marking declares that the FIXED” product is in compliance with the relevant essential requirements and other relevant provisions of Directive 1999/5/ES.

DISPOSAL INSTRUCTIONS FOR PRIVATE PERSONS(Applicable in the European Union and in countries with separate waste collection systems)

This symbol means that the product cannot be disposed of with normal household waste. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate the product from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Private individuals can contact the point of sale where the product was purchased or the local office for information on recycling this type of product. Juridical persons should contact their supplier and check the conditions of the purchase contract. Never dispose of the product with normal household waste. We strongly advise you to take your product to an official collection point to have a professional remove the battery. Import and distribution: RECALL s.r.o.

## Documents / Resources

	<a href="#">FIXED FIXED SMILE PRO smart tracker</a> [pdf] User Guide FIXED SMILE PRO smart tracker
--	---