Manuals+ — User Manuals Simplified.

FIXED FIXPS5-HCD-BW Hanging Charging Dock for PS5 DualSense Controller User Manual

Contents

FIXPS5-HCD-BW Hanging Charging Dock for PS5 DualSense Controller

FIXED Hanging Charging Dock for PS5 DualSense Controller

Product Information

- LED indicating that the driver is charging
- Driver charging port (pin)
- USB-C connector for charging station
- Two installation options: Console Mounted and Wall Mounted
- Input: DC 5V/1A
- Driver charging time: approx. 2.5 h
- Dimensions: 100*100*170 mm
- Weight: 173 g
- Material: ABS, PC

Product Usage Instructions

On the PS5 Console

1. Insert the mounting plate from the top of the PS5 console.
2. Carefully slide the charging dock from the top into the mounting plate.

On a Wall

1. Attach the installation plate to the wall and mark the holes for drilling.
2. Drill holes in the wall according to the size of the screws and insert dowels into the holes.
3. Then screw the plate into the prepared holes.
4. Carefully slide the charging dock onto the installation plates from the top.

Instructions for Use

1. Connect the cable to the USB-C port on the dock.
2. Then connect the cable to your adapter that has enough power to supply the charging station with power (we recommend an adapter with a minimum of 10W charging power).
3. Plug the adapter into a power outlet.
4. You can then attach the DualSense controller to the charging station pins and charging will start immediately.
5. Slide the earphone hook down/up as needed.

LED Indication

- Red – indicates charging
- Blue – the controller is fully charged
- LED blinking – overvoltage or undervoltage detected

Notes: The product is warranted according to the legal regulations in the countries where it is sold. In case of service problems, please contact the dealer from whom you purchased the equipment. FIXED assumes no liability for damages caused by improper use of the product.

Product Care and Maintenance

Use a soft cloth to clean the product.

Troubleshooting

If you have any problems with your product, you can contact our support at **www.fixed.zone/support**

Certification: This product is CE marked in accordance with EMC Directive 2014/35/EU and RoHS Directive 2011/65/EU. FIXED.zone a.s. hereby declares that this product complies with the essential requirements and other relevant provisions of EMC Directives 2014/35/EU and 2011/65/EU.

Thank you for purchasing the FIXED Hanging Charging Dock for PS5 DualSense Controller.

1. LED indicating that the driver is charging
2. Driver charging port (pin)
3. USB-C connector for charging station

CONSOLE MOUNTED

CONSOLE
FACEPLATE

WALL MOUNTED

WALL

READ THIS MANUAL BEFORE USE
The hanging charging dock has two installation options.

ON THE PS5 CONSOLE

1. Insert the mounting plate from the top of the PS5 console.

2. Carefully slide the charging dock from the top into the mounting plate.

ON A WALL

1. Attach the installation plate to the wall and mark the holes for drilling.
2. Drill holes in the wall according to the size of the screws and insert dowels into the holes.
3. Then screw the plate into the prepared holes.
4. Carefully slide the charging dock onto the installation plates from the top.

INSTRUCTIONS FOR USE

1. Connect the cable to the USB-C port on the dock
2. Then connect the cable to your adapter that has enough power to supply the charging station with power (we recommend an adapter with a minimum of 10W charging power).
3. Plug the adapter into a power outlet.
4. You can then attach the DualSense controller to the charging station pins and charging will start immediately.
5. Slide the earphone hook down/up as needed.

LED INDICATION

- Red – indicates charging
- Blue – the controller is fully charged
- LED blinking – overvoltage or under voltage detected

PRODUCT SPECIFICATIONS

- Input: DC 5V/1A
- Driver charging time: approx. 2.5 h
- Dimensions: 100*100*170 mm
- Weight: 173 g
- Material: ABS, PC

INCLUDED IN THE PACKAGE

- 1x charging dock for PS5 Dual Sense controller
- 4x dowel
- 4x screw
- 1x PS5 console installation plate
- 1x wall mounting plate
- 1x user manual
- 1x USB-A to USB-C charging cable

NOTES
The product is warranted according to the legal regulations in the countries where it is sold. In case of service problems, please contact the dealer from whom you purchased the equipment. FIXED assumes no liability for

damages caused by improper use of the product.

PRODUCT CARE AND MAINTENANCE
Use a soft cloth to clean the product.

SECURITY MEASURESÍ
Do not expose the device to rain or snow or immerse it in water. Do not leave the product in the car in the sun. Do not expose the device directly to sunlight or leave it near heat sources. Do not use the device if it has been heavily impacted, dropped, or damaged in any way. Do not disassemble the device, there is a risk of electric shock and/or burns. Do not modify the power cord. Keep the device out of the reach of children. Unauthorized opening or modification of product parts will void the warranty.

PRODUCT TROUBLESHOOTING

If you have any problems with your product, you can contact our support at **www.fixed.zone/support**

This product is CE marked in accordance with EMC Directive 2014/35/EU and RoHS Directive 2011/65/EU. FIXED. zone a.s. hereby declares that this product complies with the essential requirements and other relevant provisions of EMC Directives 2014/35/EU and 2011/65/EU.

FIXED.zone a.s.
Kubatova 6
České Budějovice 37004
Czech Republic

Documents / Resources

	FIXED FIXPS5-HCD-BW Hanging Charging Dock for PS5 DualSense Controller [pdf] User Manual FIXPS5-HCD-BW, FIXPS5-HCD-BW Hanging Charging Dock for PS5 DualSense Controller, Hanging Charging Dock for PS5 DualSense Controller, Charging Dock for PS5 DualSense Controller, PS5 DualSense Controller

Manuals+,