



## FLASHPOINT Telescopic Handle SpeedPod+ Instructions

[Home](#) » [FLASHPOINT](#) » FLASHPOINT Telescopic Handle SpeedPod+ Instructions 

### Contents

- [1 FLASHPOINT Telescopic Handle SpeedPod](#)
- [2 Setting up Instructions](#)
- [3 Using Your Handle](#)
- [4 One Year Flashpoint Limited Warranty](#)
  - [4.1 Question about our product line?](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)



**FLASHPOINT Telescopic Handle SpeedPod**



## Setting up Instructions

1. Use the flip locks to adjust the length



2. Mount the bracket you want to use on the top stud and tighten securely



3. Use two small knobs to adjust the position of the swivel handle



4. Use the large side knob to adjust the tilt angle of the swivel handle



5. Use the slip lock to adjust the length of the strap




6. Position the strap so that the pocket points downward then insert the base of the pole



## Using Your Handle


1. Using the handle with the compact softbox



2. This handle can be used with standard flash bracket



3. The handle can be used with both hands without strap



4. The handle can be used using both hands with the strap



## One Year Flashpoint Limited Warranty

Flashpoint warrants to the original purchaser that your Flashpoint product shall be free from defects in material and workmanship for the period of one (1) year from the date of purchase (or delivery as may be required in certain jurisdictions), or thirty (30) days after replacement, whichever comes later.

Flash point's entire liability and your exclusive remedy for any breach of warranty shall be, at Flashpoint's option, to repair or replace the hardware, provided that the hardware is returned to the point of purchase or such other place as Flashpoint may direct with a copy of the sales receipt or dated itemized receipt. Flashpoint may, at its option, replace your product, offer to provide a functionally equivalent product, or repair any product with new, refurbished or used parts as long as such parts are in compliance with the product's technical specifications. Any replacement hardware product will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer, or for any additional period of time that may be applicable in your jurisdiction. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover problems or damage resulting from accident, abuse, misapplication, or any

unauthorized repair, modification or disassembly, improper operation or maintenance, normal wear and tear, or usage not in accordance with product instructions or connection to improper voltage supply, use of consumables, such as replacement batteries, not supplied by Flashpoint, except where such restriction is prohibited by applicable law.

Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser and the country in which the product was purchased. This warranty gives you specific legal rights, and you may also have other rights, including a longer warranty duration that may vary under local laws.

To start a warranty claim contact the Flashpoint Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Flashpoint, along with the RMA number and proof of purchase.

**Question about our product line?**

### **Need Product Support?**

We are proud of our products and celebrate our customers. We are with you, from product selection to everyday use. Be secure with your purchase and reach us as you need.

**Email us:** [brands@adorama.com](mailto:brands@adorama.com)

**Call:** 212-647-9300


**Address:** Adorama Brands, 42 West 18th Street, New York, NY 10011

You can always contact us at [BRANDS@ADORAMA.COM](mailto:BRANDS@ADORAMA.COM) for personal technical support. Our web site contains a wide range of Support and FAQ pages with valuable technical assistance.

Flashpoint is a registered trademark of ADORAMA CAMERA.



### **Documents / Resources**

	<p><a href="#">FLASHPOINT Telescopic Handle SpeedPod+ [pdf] Instructions</a> FLASHPOINT, Telescopic Handle, SpeedPod</p>
---	--