


FLEXIT CS2500 Automatic Control Instruction Manual

Home » FLEXIT » FLEXIT CS2500 Automatic Control Instruction Manual

FLEXIT CS2500 Automatic Control Instruction Manual




Contents

- 1 INSTALLATION INSTRUCTIONS
- **2 CUSTOMER SUPPORT**
- 3 Documents / Resources

INSTALLATION INSTRUCTIONS

1. Insert the SD card into the controller



Plassering av SD-minnekort

2. Log in with password 2000

Startside > Hovedmeny > Enter PIN

Startsida > Huvudmeny > Ange PIN

Start page > Main menu > Enter PIN


3. Load set parameters to the SD card

Startside > Hovedmeny >
Systeminstilling > Lagre/tilbakest >
Lagre > Eks.minne

Startsida > Huvudmeny >
Systeminställn. > Spara/Återställ >
Ladda param. > Ext.m

Start page > Main menu > System
objects > Save/Load > Sett.load >
Ext.m


4. Switch off the power to the unit




5. Take a narrow object, press and hold the button down into the hole.

Apply the voltage (while the button is pressed) until the BSP LED starts flashing red/green (may take a few seconds).


Wait until the controller has restarted and the screen looks like the pictures, then restart the controller by turning off/on the power



ProPanel



ProTouch




ProTouch

6. Load set parameters from the SD card



Wait until:



Then restart the controller:





Now the controller is updated, previous settings are stored.

CUSTOMER SUPPORT

Our products are subject to continuous development and we therefore reserve the right to make changes. We also disclaim liability for any printing errors that may occur.

Flexit AS
Tel: +47 69 81 00 00
Email: post@flexit.no
Web: www.flexit.no



Documents / Resources



FLEXIT CS2500 Automatic Control [pdf] Instruction Manual CS2500 Automatic Control, CS2500, Automatic Control