

FOCAL THEVA Bookshelf Speaker



FOCAL THEVA Bookshelf Speaker User Guide

[Home](#) » [FOCAL](#) » FOCAL THEVA Bookshelf Speaker User Guide 

Contents

- [1 FOCAL THEVA Bookshelf Speaker](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 What Include](#)
- [6 Installation Instruction](#)
- [7 IMPORTANT SAFETY INSTRUCTIONS](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



FOCAL THEVA Bookshelf Speaker



Product Information

Specifications

- Model: Theva
- Configuration: Center & Surround
- Quantity: A – 4, B – 1, C – 1, D – 4, E – 1, F – 1, G – 1
- Subwoofer: Yes
- Surround Sound: Yes
- Channels: 5.1, 7.1

Product Usage Instructions

Step 1: Unpack the Product

After receiving the product, carefully remove it from the packaging. Ensure that you keep the packaging out of the reach of children to avoid any suffocation risks.

Step 2: Placement of Components

The Theva Center should be placed in a central position, while the Theva Surround should be placed in appropriate positions for optimal surround sound experience. Refer to the user manual for detailed instructions on component placement.

Step 3: Connection

Connect the components as follows:

- Theva Surround: Connect components A, B, F, and G.
- Theva Center: Connect components C, D, E, and G.
- Subwoofer: Connect to the appropriate channel (5.1 or 7.1).

Step 4: Power On and Settings

Power on the system and adjust the settings according to your preferences. Refer to the user manual for detailed instructions on system setup and settings.

Step 5: Enjoyment

You are now ready to enjoy the immersive sound experience provided by the Theva Center & Surround. Adjust the volume to a comfortable level and sit back to enjoy your favorite audio content.

FAQ

Q: What is the warranty coverage for Focal loudspeakers?

A: All Focal loudspeakers are covered by warranty provided by the official Focal distributor in your country. The warranty coverage extends at least to that granted by the legal warranty in force in the country where the original purchase invoice was issued. Please contact your distributor for specific details.

Q: Are there any safety precautions I should be aware of?

A: Yes, there are important safety instructions to consider:

- Avoid listening to loudspeakers at high volumes for long periods of time to prevent potential hearing damage.
- Keep the packaging out of the reach of children to avoid suffocation risks.
- Users who are not self-sufficient, such as children under 14 or individuals with certain disabilities, should be supervised and/or accompanied when using the device.

FIRST STEPS WITH THEVA




GO TO THE USER MANUAL









- www.focal.com/usermanual/theva

What Include




Installation Instruction








4



5



IMPORTANT SAFETY INSTRUCTIONS



Warning symbol. This symbol is designed to warn the user of the presence of important instructions mentioned in the user manual and relating to the handling, operation and maintenance of the device.

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Only use attachments/accessories specified by the manufacturer.
10. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus.
When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



11. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
12. When using the device, the ambient temperature should not exceed 95°F (35 degrees Celsius).
13. Do not use this device in tropical climates.
14. Do not place naked flame sources, such as lit candles, near the device.
15. The appliance should only be mounted on a wall or ceiling if the manufacturer allows for this.
16. This product has sharp corners. Handle it with care.
17. Do not attempt to repair this device yourself. Opening the device may be dangerous. Contact a qualified professional for all work on the device.
18. When replacement components are needed, use only the components specified by the manufacturer or components with identical technical features to those of the original product. Using non-compliant components could cause fires, electric shocks or other risks.
19. After any maintenance or repair work on the device, test it to check that it is working safely.
20. Turn the source to minimum before connecting the products and turning up the volume. Once the products are in place, gradually increase the volume to a reasonable and comfortable level.
21. To avoid damaging your hearing, do not listen to loudspeakers at high volumes for long periods of time.
Listening to loudspeakers at an excessive volume can cause damage to the user's ears and may lead to hearing problems (temporary or permanent deafness, buzzing in the ears, tinnitus, hyperacusis). Exposing your ears to a volume higher than 85dB SPL-LAeq for several hours can irreversibly damage your hearing.



22. After removing the product from its packaging, keep the packaging out of the reach of children. It could present a suffocation risk.
23. Some users who are not self-sufficient enough to use the product on their own without danger. In particular,

children under 14 or people with some types of disabilities must be supervised and/or accompanied when using the device.

Conditions of warranty

All Focal loudspeakers are covered by a warranty drawn up by the official Focal distributor in your country. Your distributor can provide all details concerning the conditions of warranty. Warranty cover extends at least to that granted by the legal warranty in force in the country where the original purchase invoice was issued.

REGISTER YOUR PRODUCT ONLINE



- www.focal.com/warranty




can QR code for information on packaging disposal



Focal-JMlab® – BP 374 – 108, rue de l'Avenir – 42353

- France – www.focal.com
- Tel. (+33) 04 77 43 57 00 – SCLC – 29/11/2023 – v2 – CODO3002

	<p>FOCAL THEVA Bookshelf Speaker [pdf] User Guide</p> <p>THEVA Bookshelf Speaker, THEVA, Bookshelf Speaker, Speaker</p>
---	---

References

- [🇺🇸 USA | Focal](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.