



Contents [[hide](#)]

- [1 FOL PRO FS-R213 Portable Wireless Speaker System](#)
- [2 Specifications](#)
- [3 Accessories](#)
- [4 Functional panel diagram](#)
- [5 Button function description](#)
- [6 FCC Warning](#)
- [7 FAQs](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)



FOL PRO FS-R213 Portable Wireless Speaker System




Specifications

- **Speaker Size:** 4"+2.25"x2
- **Frequency Response:** 50Hz – 20KHz
- **SIN Ratio:**278dB
- **Output Power:** 30W+10Wx2
- **Power:** 5V – 2A
- **Battery Capacity:**7.4V-4000mAh



Accessories

- Audio cable
- Charging line
- Instruction manual

Functional panel diagram



Button function description

1. **M**: Press this button to directly enter Bluetooth mode, then press to enter IJSB-FM Line mode, and then press to return to Bluetooth mode. Inserting a USB flash drive will be a priority in any mode.
2. " - ": Short press the previous song, in FM mode, short press this button to point to the previous channel.
3.  Pressing them within a few seconds will lower the volume.
4.  Long press to turn on, long press again to turn off. When the speaker is in a dead state, press and hold the power button for 8 seconds to restore the speaker to its initial state.
5. Short-press to enter Bluetooth mode and start connecting to the phone. After a successful connection, the Bluetooth indicator light remains on. Press 1-2 seconds to start TWS pairing connection. After a successful connection, the Bluetooth indicator lights on both speakers remain on. Double click to disconnect the Bluetooth connection of the phone once, and double click to disconnect the TWS connection twice.

6. “+”: Short press the next song, and in FM mode, use this button to short press the next channel; Press for a few seconds, and it will turn up the volume.
7. ►||: Short press to continue/stop. In FM mode, short press to mute, long press to automatically search for channels. During channel search, if short short-press is made, it will stop searching.
8. Battery indicator light
9. Audio cable insertion port
10. **USB:** USB input
11. Charging Port Type-C, 5V-2A

FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and radiates radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may

cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 0 cm between the radiator and your body.

FAQs


Q: What should I do if the speaker is not connecting via Bluetooth?

A: Make sure the speaker is in Bluetooth mode and within range of the device you are trying to connect to. Also, check if the Bluetooth function on your device is turned on.

Q: How can I charge the speaker?

A: Use the provided charging line to connect the speaker to a power source. Ensure that the power source provides a voltage of 5V and a current of at least 2A.

Documents / Resources

	FOL PRO FS-R213 Portable Wireless Speaker System [pdf] Instruction Manual FS-R213LS, FS-R213 Portable Wireless Speaker System, FS-R213, Portable Wireless Speaker System, Wireless Speaker System, Speaker System, System
---	--

References

- [User Manual](#)

■ FOL

PRO

◆ FOL PRO, FS-R213, FS-R213 Portable Wireless Speaker System, FS-R213LS, Portable Wireless Speaker System, Speaker System, System, Wireless Speaker System

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.