



## formlabs Form Wash L 3D Printer User Guide

[Home](#) » [formlabs](#) » formlabs Form Wash L 3D Printer User Guide

### Contents [ [hide](#) ]






- [1 formlabs Form Wash L 3D Printer](#)
- [2 INSTALLATION INSTRUCTIONS](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)



**formlabs Form Wash L 3D Printer**




## INSTALLATION INSTRUCTIONS



1. Remove the outer box.
2. Cut the tape, remove the top foam, and unpack accessories.
3. Use the cardboard slings to lift the machine off of the base
4. Carry machine near final position.
5. Slide the cardboard slings out from under the machine
6. Connect wifi antenna.
7. Connect the power cable to the machine and an outlet
8. Power on the machine.
9. Refer to the screen for further instructions.

## Documents / Resources

|   |  |
|---|--|
|  | <p><a href="#">formlabs Form Wash L 3D Printer</a> [pdf] User Guide<br/>106572-01, Form Wash L 3D Printer, Form Wash L, 3D Printer</p> |
|---|--|