



FPC SECURITY FPC-6377 Wireless Keypad and Wireless Exit Button Entry Kits Installation Guide

[Home](#) » [FPC SECURITY](#) » FPC SECURITY FPC-6377 Wireless Keypad and Wireless Exit Button Entry Kits Installation Guide 

Contents

- [1 FPC SECURITY FPC-6377 Wireless Keypad and Wireless Exit Button Entry Kit](#)
- [2 OVERVIEW](#)
- [3 ATTENTION! QUICK TIPS, MUST READ BEFORE INSTALLING](#)
- [4 Need assistance](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)




FPC SECURITY FPC-6377 Wireless Keypad and Wireless Exit Button Entry Kit



This Diagram is for kits: FPC-6377, FPC-6378, FPC-6379, FPC-6380, FPC-6381, FPC-6382

OVERVIEW



ATTENTION! QUICK TIPS, MUST READ BEFORE INSTALLING

- You will only need to hardwire the power supply to the mini Receiver and from any electric lock to the receiver.
- The Keypad and Exit buttons are 100% completely wireless. Installation is easier, no wire is needed to connect these devices. Just mount it on the wall and you are good to go.

- In order to properly install this kit it is recommended that you use 18/2 or 20/2 gauge wire
- Before installing this kit, check with your local fire Authority for compliance of fire codes.
- We are not responsible for the improper Installation of this kit. This is an example of how it should be installed but all applications are different.
- If you are not handy with electrical components, please consult with a certified electrician or Locksmith.
- Make sure that when you are installing this kit, please have all components turned off. We are not responsible for any type of short circuits.

Need assistance

- **Contact Us:** 1-888-504-3318
- support@fpc-security.com
- www.fpc-security.com

Documents / Resources



[FPC SECURITY FPC-6377 Wireless Keypad and Wireless Exit Button Entry Kits](#) [pdf] Installation Guide
 FPC-6377, Wireless Keypad and Wireless Exit Button Entry Kits, FPC-6377 Wireless Keypad and Wireless Exit Button Entry Kits

[Manuals+](#)