



frameo RM101, RM102 WiFi Digital Photo Frame User Manual

[Home](#) » [frameo](#) » frameo RM101, RM102 WiFi Digital Photo Frame User Manual 

Contents

- [1 frameo RM101, RM102 WiFi Digital Photo Frame](#)
- [2 FRAME FEATURES](#)
- [3 INSTALL PHOTO FRAME](#)
 - [3.1 Start using frameo](#)
- [4 SETTINGS](#)
- [5 FAQ](#)
- [6 FCC STATMENT](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)



frameo RM101, RM102 WiFi Digital Photo Frame




FRAME FEATURES

10.1 inch IPS touch screen




RM101

10.1 inch IPS touch screen



RM102




1. Wall-mounted hole
2. Power on/off button
3. Reset slot
4. Micro USB


5. Micro SD
6. DC
7. Loudspeaker

INSTALL PHOTO FRAME

1. Screw in the stand



2. Connect the power cable



GETTING STARTED


Thank you for purchasing your very own frameo.

- Set up your frame according to the “Quick start guide” when you first start the frame.
If you are new user of Frameo App, please start by following the Frameo quick set up on user manual or follow the on-screen guide when power on the frame at the first time.
- Once you have set up your Frameo frame. start connecting it to your friends and family.

FRAMEO APP

Download the Frameo App

Please download and install the Frameo App in your smartphone by searching “frameo” or scan QR code in the App Store or Google Play.



Frameo quick setup

When starting your frame for the first time, you will need to setup the frame.


- Select a language which will be used on the frame.
- Connect your frame to 2.4GHz Wi-Fi(not support 5GHz and hidden VWi-Fi).
- Set time zone, date and time if they are not correct.
- Frameo may ask you to update to the latest version. It is recommended to update your frame before continuing if asked to.
- Enter your name, and the location where you have placed your frame e.g. "Living room", "Kitchen" or "Office".

Start using frameo

- Start by connecting with your friends and family by providing them with a unique code from your frame.
- If you want to be able to send photos to the frame yourself, start by downloading the app for iOS or Android on App Store or Google Play.
- Then use the code to connect your frame and app as described below.

Connecting a new friend:

- Make sure that your friend has downloaded and installed the frameo app.
- Click the add friend icon on your frame. A dialog will appear showing a unique code which is valid for 12 hours.
- Now share this code in whatever fashion you prefer e.g. SMS, E-Mail, IM, phone call., to your friend.
- Once your friends have added the code in their frameo app, they will automatically appear on your frame and be able to send you photos.



Navigating your frameo

Swipe left or right to go through your photos.
To access the menu, simply tap once on the screen.

In the menu you will find the most used features:



Add friend:

This will generate a code that you can share with your friends and family so they can connect and send photos to your frame.

Settings

Power menu



Power off, restart frame, sleep mode.

React



Tap one of the reactions to let the sender know how it made you feel.

NB. The React menu can also be accessed by double-tapping on the screen.



Hide photo:

Hides the current photo. This means that the photo will no longer be shown in the slideshow. If needed the photo can be shown again through the settings menu.


Gallery

Opens a gallery which allows for easy and fast navigation through your photos.





Fit to frame/ Fill frame:

The Fill frame option is the default, the photo is scaled so that it fills the whole screen. It will show the most important part. Fit to frame will make sure that the entire photo is shown on the screen.



Adjust photo:

Allows you to adjust the position of the photo in the frame for an even better fit. Here you can also use  to rotate your photo, and you can use  to edit the caption on imported photos from SD card.
Note: Not support to edit caption on pictures received from App.








SETTINGS

Through settings, you can personalize your frame to your needs.

1. My frame



- **Frame name:** Changes the name of your frame. This is also the name the connected friends and family will see in their list of connected frames.
- **Frame location:** Changes the location of your frame. This is the location displayed on your friends' and family's list of connected frames which can help to distinguish frames from each other.
- **Set language:** Sets the language throughout your frame.
- **Set time zone:** Sets the timezone that should be used on your frame.
Frame will automatically try to set the correct date and time when connected to the internet.

2. Manage photos

- **Show/hide photos:** Select which photos to hide by tapping the particular photos you wish to hide. Hidden photos will NOT be deleted from your frame, you can always select them to be shown again. Use to  hide or show all photos.
- **Delete photos:** Select photos that you want to permanently delete from your frame by tapping the photo. Use  to select or deselect all and  to delete the selected photos.
- **Import photos:** Allows you to import photos from a SD card.
Before import photos, make sure you have inserted the SD card into the frame with the photos and videos.
Select the photos and videos you want to import, then tap the import button  Use  to select or deselect all photos. Use  to set the sort order of files before import, use  to order by ascending/descending.
- **Export photos:** Allows you to export photos and videos from the frame to SD card.

3. My Friends

This list contains all the connected friends that are allowed to send photos to your frame.

- **Add person:** To allow a new person to send you photos, simply tap the add friend button  and share the connection code in whatever way you prefer.
- **Allow friend to share the code to the frame:** click the options icon , if the allow button is on, the friend can retrieve and share the code to the frame from his/her app account.
- **Delete a friend:** Pressing the DELETE FRIEND will remove the friend from the list and thereby remove their permission to send photos to the frame. You will then be asked to confirm the removal and if you would like to remove all photos previously received from this friend.

4. Display and slideshow

- **Brightness level:** Adjust the brightness level of the screen.

Sleep mode: frameo offers a sleep mode which turns off the screen to reduce power consumption while you e.g. are sleeping. Its default setting is to turn off the screen at 23:00 and turn on the screen again at 07:00. To change this just set the sleep mode start/end time.

Your frame is not powered down or in standby, so you will still be able to receive photos during sleep mode. To turn off the sleep mode, just set the same start/end time.

- **Timer:** Define the duration a photo should be displayed.
 - **Show caption:** Sets whether or not to display the captions that your friends have sent with the photo. Check to display captions. Uncheck to hide captions.
 - **Fill frame:** Close it to show the original picture, default setting is turn-on.
 - **Photo display order:** By date or Shuffle is your option.
 - **Video settings:** Including autoplay setting, video playback, video volume, and auto mute.
- Frame background: Choose between several different frame background options to be shown as bars if the photo does not fill the screen.

5. Wi-Fi

- Set which Wi-Fi the frame connects to. If you are connecting to a network with a captive portal, connection status will say that Wi-Fi login is required and show. Tap this to open a login screen where you can enter credentials to access the network.

6. Backup and Restore

- Backup frame to SD card: Tap to make a backup of your photos, friends and settings. The time of latest successful backup will be displayed.
(Any existing backup on the SD card will be overridden!)
- Automatic backup: If checked, your frame will automatically take a backup within 30 hours of you receiving new photos or making changes on your frame.
- Restore from backup: Before you attempt to restore your frame, start by confirming that your backup is up-to-date. If you wish to restore a backup on a frame that has already been setup, then you must first reset the frame. This is done by pressing the "Reset frame" button. This will delete all data on the frame and reset the frame to its setup screen.
- On the setup screen you can select the "Restore from backup" button which will restore your frame from the backup.
- If the "Restore from backup" button isn't visible, then confirm that the SD card is correctly mounted.
- **Reset frame:** Removes all data from your frame. This will permanently remove all your photos, friends/connections and settings.

7. About

- Check for update: Check if an update is available for your frame.

8. Help:

- **Guid:** Opens the quick start guide, that was shown when you first started the frame.
- **Share anonymous analytics data:** Sharing anonymous analytics data helps us tremendously with improving the frameo software. We understand if you do not wish to share this data with us. Set checked if you wish to help us improve frameo. Set unchecked to deny the sharing of anonymous analytics data.

FAQ

1. Do I have to keep this photo frame plugged all the time?

Yes, you have to keep it plugged in to keep the frame on as it has no built-in battery.

2. Does this frame have to be Wifi connected to work or just in the setup process?

This frame needs to connect to a Wifi network for receiving new photos/videos and software updates. Other than that, the frame can only play the photos/videos without Wifi connection.

3. Why this frame cannot connect to Wifi?

It supports only 2.4GHz Wifi network, select the Wifi network you would like to connect and enter the password correctly if required. If your Wifi network is NOT on the list, move your frame closer to your router or restart your frame, wait for seconds and check it again. Also you could try to share your smartphone's hotspot to check.

4. Can this frame be hanged on the wall?

You can hang it on the wall by the wall-mountable hole on the back.

5. Can I place the frame in portrait or landscape position?

It can be positioned landscape or portrait.

6. How do I unbind a user?

If you would like to unbind a user, please go to the settings > my friends and click the bound user you want to delete.

7. Can this frame automatically turn on/off at a specific time?

You can set a time period for the frame to sleep regularly under sleep mode in the frame settings.

8. Can I adjust the speed the photos changes?

You can choose your Timer of your slideshow from 1 s to 24 h in the frame settings.

9. Will it start displaying photos automatically after insert a SD card?

No, after insert the SD card to the frame, you need to import photos and videos from SD card to internal storage of the frame by going to [Settings]>>[Manage photos]>[Import photos], after import, go backward to main interface to start slideshow.

10. Why I got my photos cropped on the frame?

Please choose turn-off the fill frame feature in the Slideshow settings

11. Can I cycle pictures and videos together?

Yes, you could cycle play the pictures and videos together

12. Why does it say "not in the range" or "Disable" after I enter the correct Wi-Fi password?

Please check the Wi-Fi strength in the frame, if it's not strong, connect to another Wi-Fi with stronger signal strength or connect to your smartphone's hotspot for try.

13. Can I link multiple frames to one account and send same photos to all the frame at the same time?

Yes, currently one client account can be bound to 512pcs photo frames, and one photo frame can be bound to 512pcs client accounts.

14. Can you delete the photos in the internal storage?

Yes, you can delete one or multiple photos under [Settings]>>>[Manage photos] on the frame, after delete it will release memory space from your frame.

15. Do I need to register a new account on Frameo App for binding to the frame?

No, just simply enter a user name when first use Frameo, after you enter the code, it will bind the app to the frame automatically.

16. Do I need to be connected to the same Wifi when I upload pictures to the frame by app?

No, bind the app account with the frame, you could upload pictures and videos from smartphones to the frame anywhere and at anytime. Just make sure the frame is connect to Wi-Fi during upload.

17. Can you send multiple pictures or videos at one time?

You can't send pictures and videos at one time. It supports uploading 10 photos or one video each time, please cut the video to 15 seconds before uploading.

18. Can it play groundmusic during the picture slideshow?

This frame does not support playing background music during slideshow.

FCC STATMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not Occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ i v technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Documents / Resources

	frameo RM101, RM102 WiFi Digital Photo Frame [pdf] User Manual RM101 RM102 WiFi Digital Photo Frame, RM101 WiFi Digital Photo Frame, RM102 WiFi Digital Photo Frame, F131, 2A466-F131, 2A466F131, WiFi Digital Photo Frame, WiFi Photo Frame, Digital Photo Frame, Photo Frame, Digital Frame, Frame, RM101, RM102
--	---