

FRANKEVER FK-UFO-R4 Remote-Control Extender User Manual

Home » Support » FRANKEVER FK-UFO-R4 Remote-Control Extender User Manual

Contents

- 1 FRANKEVER FK-UFO-R4 Remote-Control Extender
- 2 Specification
- 3 How to Set up
- **4 FREQUENTLY ASKED QUESTIONS**
- **5 VIDEO PRODUCT OVERVIEW**



FRANKEVER FK-UFO-R4 Remote-Control Extender



Thanks for choosing our product

Say goodbye to use one remote for each of IR home appliances such as TV,Air conditioner,Set-Top Box,etc. Please kindly read the user manual before usage and keep it for future reference.

Product Presentation:



Remark: please place it like the front side when use

Specification

1. Input:DC 5V/1A

2. IR Frequency:38-56K Hz3. WiFi Frequency:2.4GHz

4. Infrared Range: ≤ 10 meters

5. Working temperature: 0°C-50°C

6. Working humidity: ≤85%RH


7. **Size:** 68*68*17mm


8. Material: ABS

- 9. Weight:30 g
- 10. LED indicator:Blue
- 11. Supports Android 4.4 or newer and IOS 8.0 or newer

How to Set up









I Agree <u>User Agreement</u> and <u>Privacy Policy</u>




























Step1 Step2





Please Press and HoldButton To Be Copied

Step3 Step4





Step5 Step6





Please Press and HoldButton To Be Copied

Step7









Step1 Step2 Step3



Step4




Step6







Step7














FREQUENTLY ASKED QUESTIONS



DOWNIO AND A THE INCOME THE INCOM

Manuals+,