

Franklin 24911 Flexpro Net

Franklin 24911 Flexpro Net User Manual

Home » FRANKLIN » Franklin 24911 Flexpro Net User Manual

Contents

- 1 Franklin 24911 Flexpro Net
- **2 CUSTOMER SERVICE**

COMMITMENT

- **3 PARTS LIST**
- **4 ASSEMBLY INSTRUCTIONS**
- **5 Documents / Resources**
 - **5.1 References**
- **6 Related Posts**



Franklin 24911 Flexpro Net



CUSTOMER SERVICE COMMITMENT


Thank you for purchasing this Franklin® product. If the product you've purchased has missing or damaged parts, please contact us at: parts@franklinsports.com OF Visit our website at: franklinsports.com/instructions If possible, please include the product part number and parts description so we can best assist you.

WE'RE HERE FOR YOU!

PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE IT WAS PURCHASED FROM. WE ARE COMMITTED TO FULFILLING ALL REPLACEMENT PART NEEDS IMMEDIATELY.

Thank you for your continued support, and welcome to the #FranklinFamily!

PARTS LIST




ASSEMBLY INSTRUCTIONS

GENERAL NOTE

1. Find a clean, level place to begin the assembly of your Flexpro™ Net. We recommend that two adults work

together to assemble this Flexpro ™ Net.

2. Remove all components from the package and confirm all the parts are included. Please see Step 1 to begin assembly.




NOTE

Slide each black Flexpro™ sleeve on either side of the Net (#6) over each Lower Fiberglass Pole (#5). Insert each Lower Fiberglass Pole (#5) into the opening of each Base Leg (#1).


NOTE


Sexie peace o thewer fabergeach Pole (#5). Insert each Upper Fiberglass Pole Ste verang hea che silver opening of each Lower Fiberglass Pole (#5).



NOTE


To secure the top of the net, evenly slide up each Flexpro™ sleeve over the Fiberglass Poles and attach the loops on the top corners of the Net (#6) to each Upper Fiberglass Pole as shown. Secure the bottom of the Net (#6) by attaching the loops on the bottom corners to the external hooks on each Base Leg as shown.






NOTE


Attach the net to the base poles using the fastener in the middle. Then, take the (2) extra Straps (#9) and secure one on each side of the base poles to secure the net further. Secure the net further by using the Ground Stakes (#7) as shown.





Made In China Franklin Sports Inc. Stoughton, MA 02072

Documents / Resources



<u>Franklin 24911 Flexpro Net</u> [pdf] User Manual 24911 Flexpro Net, 24911, Flexpro Net, Net

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.