



# FREAKS AND GEEKS Xbox One PC Wired Controller User Manual

[Home](#) » [FREAKS AND GEEKS](#) » FREAKS AND GEEKS Xbox One PC Wired Controller User Manual 

## FREAKS AND GEEKS Xbox One PC Wired Controller User Manual



Congratulations on purchasing the premium quality gamepad.

For your personal enjoyment and safety, we recommend that you read this manual thoroughly before using this product and keep this manual handy for reference if needed.



## **Contents**

- 1 Characteristics**
- 2 INSTALLATION ON PC**
- 3 Device overview**
- 4 Documents / Resources**
  - 4.1 References**

## **Characteristics**

- Support : Xbox one/PC (X-input)
- 2 High precision analog joysticks for a 360 degree control
- Charging cable length: 3M
- Two motors for Double vibration
- 12 buttons with Turbo function
- Plug and Play

## **INSTALLATION ON XBOX SERIE X/S AND XBOX ONE**

- Connect your controller to the console using the USB cable
- LED1~4 will blink three times and then remain lit, indicating the gamepad has connected successfully

## **INSTALLATION ON PC**

- Plug gamepad into PC through USB cable
- Plug and play on windows PC (Only support Input on PC)
- LED1~4 will blink three times and then remain lit, indicating the gamepad has connected successfully
- Compatible with Windows 10/8/7,Vista,2000,Me and Windows98/XP.
- Install vibration driver and X-input driver.(as usual-input can be installed automatically on Windows7/8/10,if installation failed, please install using our provided driver)

## **Vibration**


- The vibration function comes from the driver installed on PC.
- The vibration is automatic on the PC and Xbox one.
- Vibration can be toggled ON/OFF in the game software.

## **Turbo function**

To turn the turbo function on/off, hold the Turbo button down while pressing the button that you want put into Turbo mode.

## **Device overview**






- Do not attempt to disassemble or repair this product.
- Do not allow this product to come into contact with liquids or handle it with wet or greasy hands.
- If liquid gets in, stop using this product.
- Do not subject this product to excessive force. Do not pull on the cable or bend it sharply.
- Never hold this product by the cable.
- Keep this product and its packaging out of the reach of young children. Packaging elements may

SUPPORT ET INFOS TECHNIQUES [WWW.FREAKSANDGEEKS.FR](http://WWW.FREAKSANDGEEKS.FR)

Freaks and Geeks® is a registered trademark of Trade Invaders®. Produced and imported by Trade Invaders, 28 av. Ricardo Mazza, 34630 Saint-Thibéry, France. [www.trade-invaders.com](http://www.trade-invaders.com). All trademarks are property of their respective owners. These owners didn't design, manufacture, sponsor or endorse this product.

## Documents / Resources



[FREAKS AND GEEKS Xbox One PC Wired Controller](#) [pdf] User Manual  
803514b, Xbox One PC Wired Controller, PC Wired Controller, Wired Controller, Controller

## References



-  [Accueil - Freaks and Geeks](#)
-  [Trade Invaders](#)

Manuals+.